



OPERATING INSTRUCTIONS

Pellet boiler

pelletstar

10-60 ■

INTRODUCTION

Dear Customer!

Your heating system is powered by a HERZ pelletstar boiler system and we are pleased to be able to count you as one of our many satisfied owners of a HERZ system. The HERZ boiler is the result of years of experience and continuous improvement. Please remember that in order to be able to work properly, a well-designed product also needs to be operated and maintained correctly. We definitely recommend that you should read this documentation carefully while paying particular attention to the safety instructions. Compliance with operating procedures is required for any claims made under the manufacturer's warranty. In the event of any faults or defects, please contact your heating specialist or the HERZ Customer Service department.

Yours sincerely

HERZ – Energietechnik

Warranty / Guarantee (general information)

HERZ boiler systems come with a 5-year warranty on the boiler body, storage tanks and HERZ solar collectors. We generally guarantee freedom from defects of mobile objects purchased for a period of 2 years, to a maximum of 6.000 hours of operation. For non-moving purchased items, the guarantee is generally for a period of 3 years to a maximum for 9.000 hours of operation. Parts subject to wear are excluded from the warranty/guarantee. Furthermore, claims under warranty will not be applicable if there is no return flow temperature boost or it is not working properly, if commissioning¹ is not carried out by specialist personnel authorised by HERZ, in the case of operation without a buffer storage tank with a heating load of less than 70% of the rated output (manually stoked boilers must always be operated with a sufficiently dimensioned buffer storage tank), if hydraulic diagrams² not recommended by HERZ are used and if a non-prescribed fuel as well as pellets for non-industrial use according to ENplus, Swissspellet, DINplus or ÖNORM M 7135 resp. EN 17228-2; wood chips according to EN 17225-1/4 with specification and classes: A1, A2, B1 resp. G30, G50 according to ÖNORM M 7133; resp. log wood is used³.

Any claim to warranty services requires maintenance to be carried out on an annual basis by specialist personnel authorised by HERZ.

The general warranty period will not be extended if work is carried out under warranty. In the event of a warranty claim, the due dates for payments owed to us will not be deferred. We will only provide a guarantee if all the payments owed to us for the product supplied have been made.

The warranty will be carried out at our discretion by repairing the item purchased or replacing any defective parts, by exchanging the item or by reducing the price. Parts or goods replaced are to be returned to us at our request free of charge. Wages and costs paid out in connection with installation and removal are to be paid for by the purchaser. The same applies to all warranty services.

The Supplier shall under no circumstances be liable to the Customer, for any direct, indirect or consequential costs incurred by the Customer for works carried out on HERZ equipment.

This document is the translation from the German original. The reproduction or copying, even of extracts, may only be undertaken with the permission of the company HERZ©.

Subject to technical modifications,

Version 06/2015

¹ Maintenance by manufacturer

² Recommended hydraulic diagrams can be found in the installation manual, while hydraulic balancing will be carried out by the heating contractor

³ Furthermore, the quality of the heating water must be in accordance with ÖNORM H 5195 (current version) or VDI 2035

TABLE OF CONTENT

	page		page		
1	SAFETY NOTES.....	4	9.12	Terms and definitions	25
1.1	Basic safety information.....	5	9.12.1	Boiler	26
1.2	Installation	5	9.12.2	Buffer	30
1.3	Operation and maintenance	5	9.12.3	Hot water tank	32
1.3.1	General notes.....	5	9.12.4	Heating circuit.....	35
1.3.2	Operation	5	9.12.5	Time mode.....	40
1.3.3	Maintenance.....	6	9.12.6	Solar	41
2	WARNING NOTES	6	9.12.7	Hydraulic compensator module	43
3	FUELS.....	7	9.12.8	Net pump	44
3.1	Wood pellets.....	7	9.12.9	Zone valve	45
4	SAFETY DEVICES	8	9.12.10	External demand	46
5	SYSTEM.....	9	9.12.11	Additional boiler	48
5.1	System overview	9	9.13	Menu settings	49
5.2	Boiler	10	9.13.1	Network configuration	50
6	MODE OF OPERATION	11	9.13.2	Modbus – settings	51
6.1	Feeding system	11	9.13.3	Screensaver	52
6.2	Feeding type	11	9.13.4	Information overview.....	52
6.3	Combustion air control.....	11	9.13.5	Sending E-mails	53
6.4	Boiler operation.....	11	9.13.6	E-Mail status report.....	55
6.5	Commissioning	11	9.13.7	Server settings.....	56
6.6	Operating and impermissible temperatures.....	12	10	FAULT REPORTS AND THEIR CORRECTIONS	57
7	OPERATING CONDITIONS	12	10.1	Not indicated faults	66
8	TEMPERATURE MANAGER	14	11	MAINTENANCE SCHEDULE	67
9	T-CONTROL	15	11.1	Weekly Inspection	67
9.1	Starting the system.....	15	11.2	Monthly inspection, at least every 1000 operating hours	67
9.2	Operation and handling	16	11.3	Biannual inspection.....	70
9.3	Main menu	16	11.4	Annually inspection (service, notification).....	71
9.4	Symbols explanation	17	11.5	As needed	72
9.5	Code – entry.....	18	12	EC DECLARATION OF CONFORMITY	73
9.6	Switching on/off	19	13	INDEX DIRECTORY	74
9.7	Date and time.....	20	14	ANNEX	75
9.8	Main menu values	21	14.1	Additional boiler module.....	75
9.8.1	Adding values.....	21	14.2	Solar module.....	77
9.8.2	Delete values.....	22	15	NOTES	83
9.9	Fault messages and warnings	23			
9.10	Modules.....	24			
9.11	Module configuration.....	25			

1 SAFETY NOTES

- Before commissioning, please read the documentation carefully and pay attention to the safety instructions given in particular. Please consult this manual if anything is unclear.
- Make sure that you understand the instructions contained in this manual and that you are sufficiently informed regarding the way in which the biomass boiler system works. Should you have any queries at any time, please do not hesitate to contact HERZ.
- For safety reasons, the owner of the system must not make any changes to the construction or the state of the system without consulting the manufacturer or his authorised representative.
- Make sure that there is a sufficient supply of fresh air to the boiler room (please heed the relevant national regulations)
- All connections are to be checked before the commissioning of the system in order to make sure that they are leak-tight.
- A portable fire-extinguisher of the prescribed size is to be kept by the boiler room. (Please heed the relevant national regulations).
- When opening the door to the combustion chamber, make sure that no flue gas or sparks escape. Never leave the combustion chamber door open unattended as toxic gases may escape.
- Never heat the boiler using liquid fuels such as petrol or similar.
- Carry out maintenance regularly (in accordance with the maintenance schedule) or use our Customer Service department. (The minimum maintenance intervals specified in the TGPF are to be observed).
- When carrying out maintenance on the system or opening the control unit, the power supply is to be disconnected and the generally valid safety regulations are to be heeded.
- In the boiler room, no fuels may be stored outside the system. It is also not permitted for objects which are not required for the purpose of operating or carrying out maintenance on the system to be kept in the boiler room.
- When filling the fuel storage room using a pump truck, the boiler must always be switched off. (stamping on the filling connection cover). If this instruction is not heeded, flammable and toxic gases may get into the storage room!
- The fuel storage room is to be protected against unauthorised access.
- Always disconnect the power supply if you need to enter the fuel storage room.
- Always use low-voltage lamps in the fuel storage room (these must be approved for this type of use by the relevant manufacturer).
- The system is only to be operated using the types of fuel prescribed.
- Before the ash is transported further, it must be stored temporarily for at least 96 hours in order to let it cool down.
- Should you have any queries, please call us on +43 3357 / 42840-840.
- Initial commissioning must be carried out by the HERZ Customer Service department or an authorised specialist (otherwise any warranty claim will not be applicable).
- Ventilate fuel storage room for ~ 30 minutes before trespassing.
- The boiler meets the requirements of the Association of Swiss Canton Fire Insurance Companies or national fire safety regulations. The customer himself shall be responsible without exception for ensuring that these regulations are complied with on site!

1.1 Basic safety information



Due to its functionally limited electrical and mechanical characteristics with regard to usage, operation and maintenance, if the equipment is not able to work according to its appropriate use or improper interference occurs, it may cause serious health and material damage. It is therefore conditional that the planning and implementation of all installations, transportation, operation and maintenance will be carried out and supervised by responsible, qualified persons.



When operating electrical systems, certain parts of those systems will always carry a hazardous electrical voltage or be exposed to a mechanical load. Only appropriately qualified personnel may carry out work on the system. They must be thoroughly familiar with the content of this and all other manuals. In order for this system to function safely and without any problems, transportation, storage, operation and maintenance must be carried out properly and carefully. Instructions and information on the systems must also be heeded.

1.2 Installation

General notes

In order to ensure that the system will function properly, the relevant standards and the manufacturer's installation instructions are to be heeded during the installation of the system!

Documents from the manufacturer relating to the heating devices and components used are available from HERZ on request.

1.3 Operation and maintenance

1.3.1 General notes



Don't open the boiler doors until "HEATING OFF" is displayed, otherwise a risk of deflagration (explosion) is given.



In order for the system to be operated and maintained safely, it must be operated and maintained properly by qualified personnel while heeding the warnings in this documentation and the instructions on the systems.



In unfavourable operating conditions, the temperature of boiler housing parts may exceed 80 °C.



If the door to the ash container is opened during operation, the fuel supply will be shut off and the boiler will switch to the burnout phase. Afterwards the boiler will switch to the operating mode "HEATING OFF".

Ambient conditions		
Operating temperature:		+10 to +40 °C
Warehouse-/ transport temperature:		-20 to +70 °C
Humidity:	operation	5 to 85 %
	storage	5 to 95 %

1.3.2 Operation



Covers which prevent contact with hot or rotating parts or which are required in order to direct the flow of air correctly and thus ensure the effective functioning of the system must not be opened during operation.



In the event of a fault or unusual operating conditions such as the emission of smoke or flames, the system is to be switched off immediately by operating the emergency stop button. Notify the HERZ Customer Service department immediately.

- If the boiler room door main switch is operated or if a power failure occurs, the system will be taken out of operation immediately. The remaining quantity of residual fuel will burn independently without giving off any toxic gases, if the chimney draught is sufficiently. Therefore the chimney must be designed and produced in accordance with DIN 4705 or EN 13384. When the boiler is switched on again, the system has to be checked in order to make sure that it is fully functional and a safe operation of the whole system must be guaranteed!

- The generated system noise during operation does not present any danger to the operator's health.
- If the residual flue gas oxygen content drops below the required minimum of 5 %, the fuel supply will be stopped automatically and will not be activated again until the residual oxygen content has risen to more than 5 % (fault text: MIN O2 [%] 5.0, see chapter 9.12.1)

1.3.3 Maintenance

Before starting to carry out any work on the system, but especially before opening covers protecting live parts, the system is to be properly disconnected from the power supply. Besides the main circuits, attention is also to be paid to any existing additional or auxiliary circuits in the process. The normal safety rules according to ÖNORM are:

- Disconnect all poles and all sides!
- Ensure that the system cannot be switched on again!
- Check to ensure that no voltage is connected!
- Earth and short-circuit!
- Cover adjacent live parts and locate hazardous areas!

	These above-mentioned measures must not be reversed until the system has been fully installed and maintenance has been completed.
	Personal dust masks and gloves must be worn when carrying out maintenance in the combustion chamber or the ash collector or on flue gas-carrying parts and when emptying the ash container, etc.!
	Extra-low-voltage lamps are to be used when carrying out maintenance in the fuel storage room. Electrical equipment in the fuel storage room must be designed in accordance with ÖN M 7137!

In order to prevent any maintenance errors, if maintenance is not carried out properly, it is recommended to be carried out regularly by authorised personnel or by the HERZ Customer Service department.

Spare parts must be obtained directly from the manufacturer or a distribution partner.

2 WARNING NOTES

	Risk of injury and damage to property due to improper handling of the system. Damage to property is possible.
	Caution – hot surface
	Warning – against hand injuries.
	No admittance without authorisation.

However, adherence to guidelines for transportation, installation, operation and maintenance notices as well as technical data (in the operating instructions, product documentation and on the equipment itself) which are not specifically highlighted, is also vital to avoid breakdowns which may directly or indirectly cause major personal or material damage.

General note

For reasons of clarity and possible permutations, this documentation does not contain all detailed information and cannot take account of every conceivable operating or maintenance scenario. Should you require further information or encounter specific problems, which are not handled in detail in the documentation supplied, you can obtain the required information from your specialist dealer or direct from HERZ.

People (including children) who, because of their physical, sensory or mental capabilities or because of their lack of experience or knowledge, are unable to use the equipment safely must not use this equipment unless they are supervised or instructed by a responsible person.

3 FUELS

The HERZ pellets boiler should be operated with the fuels and their properties which are described in this chapter.

3.1 Wood pellets

Wood pellets for non-industrial use according to ENplus, Swisspellet, DINplus or ÖNORM M 7135 resp. pellets according to EN 17225-2 with following specifications:

- Property class A1
- The maximum permissible fines content in the fuel storage room must not exceed 8 % of the fuel volume (determined using a perforated screen with holes 5 mm in diameter)!
- Fines content at loading: < 1.0 m-%
- Calorific value at as-delivered condition > 4,6 kWh/kg
- Bulk density (BD) at as-delivered condition > 600 kg/m³
- Mechanical Strength (DU), EN 15210-1 at as-delivered condition in m-%: DU 97,5 ≥ 97,5
- Diameter 6 mm

Prevent the entering of debris such as stones or metal particles into the system! Sand and soil lead to higher level of ash and slagging precipitation.

There may be a formation of slag according to the fuel quality, which has to be removed by hand.

In the case of non-compliance, any warranty or guarantee will be rendered null and void. The burning of unsuitable fuels could lead to uncontrolled combustion. Operational faults and consequential damage are likely to occur.

If a different fuel is named explicitly on the order respectively the order confirmation, the system can be operated with the mentioned fuel.

Note: The system is set to the agreed fuel at the commissioning. This setting (ID-fan speed, fuel, flow and backflow, cycle times, etc.) should not be changed when using constant fuel quality.

4 SAFETY DEVICES

The safety devices must be dimensioned and installed according to EN 12828 resp. ÖN B 8133.

The safety valve in the boiler circulation serves as a final safety device against malfunctions of the equipment.

All legal safety regulations must be adhered to on-site via the authorised specialist company.

Earthing or potential equalisation must be carried out on the whole heating system according to EN 60204-1 by an authorised specialist company.

1 Safety temperature limiter

If the boiler temperature exceeds 95 °C, the equipment must be switched off for safety reasons. The safety temperature limiter (STL) will lock in this case.

Possible causes may be:

- Performance decrease in the boiler was interrupted abruptly. This can occur due to the switching off a pump or sudden shutting of the heating circuit mixer.
- The load pumps are being controlled by the HERZ Control. The so-called excess temperature flue gas would be automatically activated by the HERZ Control. This avoids higher boiler temperatures.
- The boiler is too large.
- The fuel level is set too high.
- Loss of power supply
- Etc.

At First the cause of the failure must be found and be corrected, afterwards the safety temperature limiter can be unlocked.

The boiler temperature must be lower than 75 °C before unlocking.

Only after the temperature fell below 75 °C the malfunction can be rectified. To acknowledge the malfunction unscrew the STL covering and put gentle pressure, using a sharp object, to the STL.

2 Burn-back safety unit

The burn-back safety unit prevents a burn-back into the fuel storage room. It separates additionally the combustion chamber and the fuel storage room. The burn-back safety unit is conducted like a fire flap and opens only when fuel is fed to the boiler.

3 Safety valve

The safety valve automatically releases, when the pressure or temperature exceeds preset limits. The safety valve has to release at the maximum allowable pressure (according to boiler plate).

4 Safety heat exchanger (pelletstar 45-60)

The safety heat exchanger is a built in safety device and has to be connected to a thermal release valve and installed, according to applied standards. The safety heat exchanger has to be connected directly to a cold water pipe (pressure ≤ 3 bar)

5 Ash container safety device

The ash container door is connected contact-free (inductive sensor) to the boiler.

Fuel storage room temperature monitoring

The fuel storage room temperature monitoring is placed directly above the transport screw. If the storage room temperature exceeds its preset limit, the boiler will switch to the operate condition „HEATING OFF“ and displays a fault report. Additionally a fault sensor output gets active. Conduct alerting in accordance with national standards.

5 SYSTEM

5.1 System overview

Please consider that the installed room discharge and storage room filling system can be different to the displayed system in example 1 and 2. More information can be provided by the company HERZ.

Example 1:

The discharge system contains of a flexible screw discharge system (5). The filling of the fuel storage room (2) with sloping floors (6) is carried out with blow-in support (1). The boiler (3) is combined with a buffer tank (4).




figure 5.1: System overview - example 1

Example 2:

The discharge system contains of a modular pellets screw/suction system (6) and a suction hopper (5). The filling of the fuel storage room (2) with sloping floors (7) is carried out with blow-in support (1). The boiler (3) is combined with buffer tanks (4).





figure 5.2: System overview - example 2

5.2 Boiler


pelletstar 10-60



Caption

- 1 .. ID-fan
- 2 .. Heat exchanger with integrated turbulators
- 3 .. Burn back protection device
- 4 .. Stoker screw
- 5 .. Ash container (front / back)
- 6 .. Burner
- 7 .. Pellets chute
- 8 .. Integrated control

Boiler back side



Caption

- 1 .. Bushing flow connection
- 2 .. Thermowell flow probe
- 3 .. Bushing electrical connections
- 4 .. Bushing backflow connection
- 5 .. Aperture feeding screw
- 6 .. Bushing fill and drain valve
- 7 .. Power supply
- 8 .. ID-fan

6 MODE OF OPERATION

6.1 Feeding system

The fuel is fed from the fuel storage room by the room discharge system to the burn back protection device. Fuel passes the hopper first, afterwards the back burn flap. The back burn flap gets steered by a spring loaded servo motor. If the servo motor operates current less, the back burn flap will close independently. Next the fuel is fed towards the burning chamber by the feeding screw. The achieved fuel level is a crucial factor of the boiler heat output and operating mode.

6.2 Feeding type

The operation of the pelletstar is based on a pulse-no-pulse ratio, which controls the feeding system. The feeding values are set up via the menu "Fuel values" (only available in the service area) and modulated by the combustion control system.

6.3 Combustion air control

The supplied combustion air is differentiated between primary and secondary air. The primary air is initiated directly into the embers. The secondary air gets used to actuate the developed flame to a completely. The air supply is piped via vents on the burner side (underneath side cover).

The ID-fan on the backside of the boiler generates low pressure within the boiler. The secondary- and primary air get sucked out due low pressure.

The secondary- and primary air get sucked out due low pressure. The ID-fan speed is controlled according to the boiler temperature and the lambda probe control.

6.4 Boiler operation

The boiler starts up automatically with its built-in automatic ignition, when heat is required.

The heat requirement can be controlled by the weather or by a remote sensor (optional), depending on any heating circuit. A room thermometer can also be used to generate an external requirement. The boiler can also be started up by the requirement of a hot water tank.

The boiler output can be controlled by set up values and adjusted to local conditions.

The boiler control prevents too low boiler temperatures to avoid effect on the durability of the system. Too high boiler temperatures are not permissible.

Expansion cracks at insulating plates, respectively burning chamber stones, don't affect their capacities and don't represent warranty claim.

6.5 Commissioning

The commissioning must be carried out by HERZ factory customer service or an authorised specialist.

A pressure measurement is conducted additionally after boiler has been operated with the actual fuel for > 1 hour and a flow temperature of 70-85 °C.

The result of the pressure measurement represents a characterisation of the draught during normal operation and shows, if the required draught has been reached. If a deviation occurs, the existing chimney has not been dimensioned correctly or dimensioning underlying installations have not been carried out correctly (e.g.: faulty connections, false air inflow, too long connection pipe,...) and the boiler does not operate properly.

During initial operation and commissioning the system controls and safety devices must be checked and the handling of the boiler as well as the system maintenance schedule must be explained to the operator.

The hydraulic balancing of the equipment (pipe installation) must be carried out by an authorised specialist company (installer). The installer's duty according to ÖNORM EN 12170 is to create documentation of the heating system. The documentation has to be retained in the boiler room.

6.6 Operating and impermissible temperatures

Boiler temperature

The HERZ pelletstar boiler operates at a boiler temperature between 65 °C up to 90 °C. If the return flow temperature is lower than 55 °C, flue gas will condense on the inside of the boiler. So if the boiler starts up, the operating temperature (from 65 °C to 90 °C) must be reached as quickly as possible in order to avoid condensation. The back flow temperature may also be lower than the permissible value at correct boiler operating temperature. This condition should be avoided by a back flow temperature increase.

Note!

All guarantee or warranty claims are invalidated in the event of damage by corrosion arising due to impermissible operation temperatures.

Back flow temperature

The back flow temperature is always lower than the boiler temperature. The back flow temperature must exceed 60 °C as quickly as possible, depending on the boiler type. Temperature level retention of the back flow or the boiler temperature is achieved using a so-called back flow bypass or back flow temperature monitoring. In this case the flow is admixed via a pump and a valve to the back flow.

The boiler's heat energy can only be used after the back flow temperature has exceeded 60 °C.

Too high boiler temperatures

The HERZ pelletstar boiler can be operated with a maximum boiler temperature up to 90 °C. If the decrease of performance drops suddenly (mixers shut-off, hot water tank load pump switches off) the boiler's saved heat energy can overheat the boiler.

The pelletstar boiler has three different pre-installed safety devices to prohibit a further temperature increase:

- Overheat temperature (higher than 92 °C boiler temperature)

At this temperature the connected consumer pumps get switched on in order to conduct overheat (consumer pump connection to the HERZ controls is required). At this temperature the connected consumer pumps get switched on in order to conduct overheat (consumer pump connection to the HERZ controls is required). If the consumer pumps aren't connected to the HERZ controls, a higher probability of overheating, resulting in failure, is given.

- Thermal release valve

At pelletstar 10, 20, and 30 is no thermal release valve necessary. At pelletstar 45-60 a safety heat exchanger is integrated that has to be connected to a thermal release valve.

- Safety temperature limiter – STL

If the boiler temperature exceeds 95 °C, a fault report gets indicated, the boiler gets switched off and the safety temperature limiter locks itself.

Flue gas temperature

The flue gas temperature depends on the boiler operation conditions, the fuel, the ventilator setting and the boiler type.

Observe:

The chimney must be insensitive to moisture and calculated and dimensioned according to DIN 4705 or EN 13384. HERZ does not carry out chimney calculations. The chimney calculation must be calculated by authorised personnel. A miscalculated or undimensioned chimney may lead to a malfunction of the system.

7 OPERATING CONDITIONS

Heating off

During this phase the boiler is switched off, i.e. the burner is blocked.

Ready

The boiler- respectively the buffer temperature is sufficiently high to provide the required heat load, or the boiler temperature has reached the switch off temperature.

Ignition preparation

During this phase the grate gets cleaned and the lambda probe gets pre-heated.

Pre-aeration

During the pre-aeration phase the burning chamber and the chimney get purged with fresh air.

Cold start

If the boiler room temperature is lower than the identified boiler room ignition temperature (150 °C), the boiler performs a cold start and fuel is fed to the burning chamber. In the same time the fuel gets ignited by the ignition fan. An ignition monitoring is conducted during this phase.

After successful ignition, the boiler switches to the burning phase and the ignition fan stopping time (1 minute) starts to cool down the ignition fan heating element.

If ignition wasn't possible prior the maximum ignition period (3x set up time), the boiler will switch off and the fault "IGNITION" (see fault 66) will appear in the fault list.

Scorch phase

During the scorch phase the boiler control tries to achieve an even fire bed. The length of the scorch phase can be set in the fuel value settings (only available in the service area). Pay attention to a higher oxygen content at the combustion to achieve an even fire bed faster.

Start up phase

During the start up phase the boiler operates at nominal heat output. If the boiler set temperature is reached, the boiler will switch to the regulation phase.

Regulation phase

During the regulation phase the boiler is modulated between nominal load and partial load. If boiler oversupplies heat, i.e. if the boiler target temperature + control hysteresis gets exceeded, the boiler will switch to the operating condition „ready“.

Burn out phase

If the boiler will be switched off the remaining quantity of residual fuel will burn independently. Pay attention to the burn out phase time setup, if chosen too short, fuel will not be burned accordingly.

Burner cleaning

During the burner cleaning phase ash gets removed off the grate. The boiler switches to the burn out phase and remaining fuel gets burned out. Afterwards the grate gets cleaned and the boiler switches to normal operation. The burner cleaning interval is calculated by the feeding screw operating time. The cleaning interval is set up with the parameter "cleaning interval" in the service area.



Please note that during burner cleaning phase no respectively only reduced heat output is available. Consider these cleaning intervals at your planning.

Heat exchanger cleaning

The Heat exchanger gets cleaned automatically. The cleaning interval and duration is set up in the service area with the parameter "heat exchanger cleaning interval" respectively „heat exchanger cleaning duration“.

Boiler output control

The boiler output gets modulated by the boiler set temperature + control hysteresis (= regulation end). If the regulation end is reached, the boiler will switch to the burn out phase.

Flue gas temperature control

If the maximum flue gas temperature is exceeded, the boiler output will be reduced. If the actual flue gas temperature is lower than the maximum flue gas temperature, the boiler will switch to normal output control.

Flame monitoring (burning chamber temperature)

If the burning chamber temperature fluctuates greatly during operation, the boiler will switch off.

Freezing protection

If the freezing protection operates, the back flow bypass pump will switch on only if the boiler is in operating mode "HEATING OFF" or "BURNER STOP". Otherwise (freezing protection disabled) the boiler will start up and heat up to minimum boiler temperature.

Lambda control

The amount of fuel and the rotation speed of the ID-fan are controlled by the lambda control. The control is able to detect marginal deviations of the fuel quality and induces a combustion improvement.

8 TEMPERATURE MANAGER

The heat demand of the individual modules (boiler, hot water tank, heating circuit, solar, etc.) is controlled by the temperature manager. The below-mentioned scheme (see figure 8.1) explains the functionality of the temperature manager. A module contains of an in- and output. Every module sends a required demand temperature to the temperature manager. The sent required demand temperature is a sum of an internal calculated temperature demand + set up increase. The heat supplier (= heat generator respectively boiler/hot water tank), which receives the different module demand temperatures from the temperature manager, must supply the required temperature demand to the different modules. The temperature manager calculates the maximum demand temperature of all modules.

Example:

Heat supplier = boiler

Module 1 & 2 = heating circuit 1 & 2

Module 3 = hot water tank

Module 4 = buffer

	<i>Heating circuit 1</i>	<i>Heating circuit 2</i>	<i>Hot water tank</i>	<i>Buffer</i>
calculated required temperature [°C]	60	30	55	75
Temperature increase [°C]	5	3	2	2
Required temperature of the modules [°C]	65	33	57	77

Maximum temperature requirement

77




figure 8.1: Temperature manager (simplified schema – example)

9 T-CONTROL

The handling and menu navigation are described in this chapter. Every single T-CONTROL parameter is explained in chapter 9.11 (page 25).




figure 9.1: T-CONTROL

9.1 Starting the system

To switch on the display, two conditions must be fulfilled:

- The boiler must be connected to the power supply figure 9.1

If it is fulfilled, the starting process of the display, which takes 1-2 minutes, starts.




figure 9.1: Power supply plug

9.2 Operation and handling

The touch panel is a touch-sensitive screen and control unit. By touching the screen you can change released values or move to other pages. The screen navigation and input can be done with finger, pen, pencil, etc.

9.3 Main menu

After start up figure 9.2 will appear. In the centre of the screen important values according the boiler, buffer, hot water tank, heating circuit and so on are shown. The shown values can be adapted individually (see chapter 9.3).




figure 9.2: Main menu

If the following symbol is pressed:

	the main menu will be displayed (see figure 9.2)
	fault messages (warnings & alarms) will be displayed (see chapter 10)
	the individual modules (boiler, hot water tank, buffer, heating circuit, solar, hydraulic compensator, net pump, zone valve, external demand) will be displayed. (see chapter 9.10)
	the menu settings (network configuration, E-Mail, screen saver) will be displayed (see chapter 9.13)
	the date & time can be set up (see chapter 9.7, changing with code only!)
	the code input screen will be shown (see chapter 9.5)
	the heating system can be switched on or off. (see chapter 9.6) In general the field is used to display the operating conditions (see chapter 7)
	more important values will be shown on the second page

9.4 Symbols explanation

In this section important symbols are explained.

	<p>The CHIMNEY SWEEPING FUNCTION provides a test mode for the chimney sweeper. The boiler is operated steadily at nominal output and all consumer values are set to its maximum during the chimney sweeper carries out its measurements. The measurements must be carried out after “chimney sweeping mode” appears on the display and a developed flame exists. If the maximum boiler temperature or the permissible chimney sweeping time is exceeded, the chimney sweeping function will abort. The chimney sweeping time is 25 minutes by default, the remaining time counts after boiler status “chimney sweeping mode” starts.</p>
	<p>With the aggregate-test connected components can be tested individually. The symbol is only visible, if:</p> <ul style="list-style-type: none"> • the code has been entered (see chapter 9.5, page 18) and • the boiler is in the “heating off” operation mode (only at the boiler aggregate-test!) <p>If the Aggregate-Test is active, the symbol will turn green and the message “AGG-Test ACTIVE” is shown on the display.</p>
	<p>Information such as firmware-module, hardware-module, software version etc., of each module (boiler, hot water tank, buffer, solar, heating circuit).</p>
	<p>These symbols (navigation) can be used to navigate in each module (boiler, hot water tank, buffer, solar, heating circuit, hydr. compensator, net pump, zone valve, ext. demand). An alternative to the illustrated navigation method is the wiping to the right or left.</p>
	<p>Back to the modules overview (boiler, hot water tank, buffer, solar, heating circuit, hydr. compensator, net pump, zone valve, ext. demand).</p>

9.5 Code – entry

If entering the code, the following operations can be performed:

- Setting up values
- Activation of the aggregate-test (see chapter 9.4)
- Setting up or changing of date & time (see chapter 9.7)
- Navigation in the menu settings (see chapter 9.13)

Navigation 1:		Navigation 2:	
Screen: 		Screen: 	
<p style="text-align: center;">figure 9.3: Code - entry</p>		<p style="text-align: center;">figure 9.4: Code - entry</p>	
If the following button is:		Note:	
	figure 9.4 is displayed.	Enter the corresponding code (see below) and press „OK“ to confirm.	
	the main menu will be displayed (if you have already entered a code, the control will be locked)	Code: 111	
	the previous page will be displayed	the open padlock-icon appears: 	

9.6 Switching on/off

SWITCH-ON	SWITCH-OFF								
<p>Navigation: </p> <p>Screen:</p>  <p>figure 9.5: Boiler switch-on</p>	<p>Navigation: </p> <p>Screen:</p>  <p>figure 9.6: Boiler switch-off</p>								
<p>If the following button is pressed:</p> <table border="1"> <tr> <td data-bbox="217 999 284 1048"></td> <td data-bbox="371 1005 722 1037">the boiler will be switched on.</td> </tr> <tr> <td data-bbox="217 1066 284 1128"></td> <td data-bbox="371 1055 783 1144">the boiler will switch off, remains off and the previous page will be displayed.</td> </tr> </table>		the boiler will be switched on.		the boiler will switch off, remains off and the previous page will be displayed.	<p>If the following button is pressed:</p> <table border="1"> <tr> <td data-bbox="877 999 944 1048"></td> <td data-bbox="1032 1005 1383 1037">the boiler will be switched off.</td> </tr> <tr> <td data-bbox="877 1066 944 1128"></td> <td data-bbox="1032 1070 1444 1133">the boiler remains on and the previous page will be displayed.</td> </tr> </table>		the boiler will be switched off.		the boiler remains on and the previous page will be displayed.
	the boiler will be switched on.								
	the boiler will switch off, remains off and the previous page will be displayed.								
	the boiler will be switched off.								
	the boiler remains on and the previous page will be displayed.								
<p>Note:</p> <p>The system can only be switched on, if the code (see chapter 9.5) has been entered.</p>	<p>Note:</p> <p>The boiler will switch to the operating condition “burn out phase” (except “cold start” or “ready”). If the boiler gets switched off during “burn out phase”, the cold start will be completed. Afterwards the “burn out phase” will start to prevent an unacceptable amount of fuel within the burning chamber.</p> <p>The system can only be switched off, if the code (see chapter 9.5) has been entered.</p>								
	 <p>If “chimney sweeping mode”  is active, the remaining time can be raised in 5 minutes steps by pushing the -button.</p>								


9.7 Date and time

Navigation 1:		Navigation 2:			
Screen:			Screen:		
<p>figure 9.7: Date and time selection</p>		<p>figure 9.8: General settings for NTP</p>			
If the following button is pressed:		If the following button is pressed:			
	the language can be set up.		the language can be set up.		
	the time can be set up.	NTP Server	the server name can be set up. (The server receives automatically an IP-address from the network)		
	the date can be set up	Time zone	the time zone can be set up		
	NTP can be activated (time and date will be updated automatically). If NTP is active, time and date will be updated automatically via network (= connection to the internet via LAN cable).	Act. interval	the update interval of date and time, in hours, can be set up (i.e.: every 12 hours)		
	the summer and winter time gets selected.	NTP Update	a NTP update can be carried out. The time and date will be updated immediately.		
	the screen is locked (cleaning possible)				
	the main menu will be displayed.				
Note:		<i>In case of power blackout:</i>			
NTP (Network Time Protocol) is used to synchronize date and time automatically via the network. A valid network connection via a LAN cable to the internet is required.		If NTP is active, the date and time will be updated automatically after switch-on. If NTP is not active, the date and time will be updated via an internal memory up to 10 days (manufacturer's data). If boiler is more than 10 days out of service, date and time must be set manually.			


9.8 Main menu values

9.8.1 Adding values

Navigation 1:	Code – entry (chapter 9.5)	Navigation 2:	Show value
<p>Screen:</p>  <p style="text-align: center;">figure 9.9: Adding display values</p>		<p>Screen:</p>  <p style="text-align: center;">figure 9.10: Determining display values</p>	
<p>If the following field is pressed:</p>		<p>If the following field is pressed:</p>	
<p>Show value</p>	<p>an overview of available values will be displayed (see figure 9.10)</p>	<p>Delete actual</p>	<p>the selected value can be deleted (see figure 9.14)</p>
	<p>the second page of the main menu will be displayed.</p>	<p>Load scheme</p>	<p>a default scheme gets loaded (see figure 9.11)</p>
		<p>Delete all</p>	<p>All values will be deleted (see figure 9.13)</p>
		<p>Boiler 000</p>	<p>the boiler values, which can be selected manually, will be displayed (see figure 9.12)</p>
		<p>BUFFER i000</p>	<p>the buffer values, which can be selected manually, will be displayed</p>
		<p>HOT WATER TANK i001</p>	<p>the hot water tank values, which can be selected manually, will be displayed</p>
		<p>HEATING CIRCUIT i002</p>	<p>the heating circuit values, which can be selected manually, will be displayed</p>
		<p>TIME MODE 000</p>	<p>the time mode values, which can be selected manually, will be displayed</p>
		<p>SOLAR i004</p>	<p>the solar values which, can be selected manually will, be displayed</p>

Navigation 3: Load scheme		Navigation 4: Show value → Boiler 000							
Screen:  <p>figure 9.11: Load scheme</p>		Screen:  <p>figure 9.12: Determining display values</p>							
Note: The values of the default scheme can also be adapted individually. Thereby press 3-5 seconds on the value and follow the procedure described in figure 9.12.		If the following field is pressed: <table border="1" data-bbox="801 831 1457 1077"> <tr> <td data-bbox="801 831 1024 898">Power, Back flow-must, etc.</td> <td data-bbox="1024 831 1457 898">the value will be confirmed and displayed at the main menu.</td> </tr> <tr> <td data-bbox="801 898 1024 999"></td> <td data-bbox="1024 898 1457 999">the page previous page of the individual modules will be displayed (see figure 9.10)</td> </tr> <tr> <td data-bbox="801 999 1024 1077"></td> <td data-bbox="1024 999 1457 1077">the second page will be displayed</td> </tr> </table> Note: The same procedure can be applied to all other modules.		Power, Back flow-must, etc.	the value will be confirmed and displayed at the main menu.		the page previous page of the individual modules will be displayed (see figure 9.10)		the second page will be displayed
Power, Back flow-must, etc.	the value will be confirmed and displayed at the main menu.								
	the page previous page of the individual modules will be displayed (see figure 9.10)								
	the second page will be displayed								

9.8.2 Delete values

Delete all display values		Delete optional display value	
Navigation:	Code – entry (chapter 9.5) → symbol  → show value → delete all	Navigation:	Code – entry (chapter 9.5) → press display value for 3-5 seconds → delete actual
Screen:  <p>figure 9.13: Delete all display values</p>		Screen:  <p>figure 9.14: Delete optional display value</p>	

9.9 Fault messages and warnings

Navigation:  → 

Screen:



figure 9.15: Fault messages

If the following field is pressed:

Actual	the current fault messages will be displayed.
Archive	all fault messages will be displayed.

Note:

- A red highlighted field represents an active fault (appears in the lower right box).
- An orange highlighted field represents a warning.
- A yellow highlighted field represents information (no fault has occurred).
- A highlighted green field with crossed text represents a fault or a warning which had occurred (only visible in the archive)

An overview of all errors and its correction is shown in chapter 10 (starting on page 57).

9.10 Modules

Navigation:  → 

Screen:



figure 9.16: Modules overview

If the following field is pressed:

Boiler 000	the „boiler values“ menu will be displayed (see chapter 9.12.1 – page 26)
BUFFER i000	the „buffer values“ menu will be displayed (see chapter 9.12.2 – page 30)
HOT WATER TANK i001	the „hot water tank values“ menu will be displayed (see chapter 9.12.3 – page 32)
HEATING CIRCUIT i002	the „heating circuit values“ menu will be displayed (see chapter 9.12.4 – page 35)
TIME MODE 000	the „time mode“ menu will be displayed (see chapter 9.12.5 – page 40)
SOLAR i004	the „solar values“ menu will be displayed (see chapter 9.12.6 – page 41)
HYDR. COMPENSATOR i000	the „hydr. compensator “ menu will be displayed (see chapter 9.12.7 – page 43)
NET PUMP i001	the „net pump“ menu will be displayed (see chapter 9.12.8 – page 44)
ZONE VALVE e003	the „zone valve“ menu will be displayed (see chapter 9.12.9 – page 45)
EXT: REQUIREMENT e004	the „external requirement“ menu will be displayed (see chapter 9.12.10 – page 46)
ADDITIONAL. BOILER e005	the „additional boiler“ menu will be displayed (see chapter 9.12.11– page 48)
	it is possible to navigate the module menu (up and down)

9.11 Module configuration

Boiler

Overview
Status
Settings
Suction time
Outputs
Inputs
Operating hours

Buffer

Overview
Status
Settings
Agg-Test

Hot water tank

Overview
Status
Settings
Time program
Circulation time
Agg-Test

Heating circuit

Overview
Status
Operation modes
Parameter
Heat curve
Time program
Agg-Test

Time mode

Time program
Settings

Solar

Overview
Status
Settings
Agg-Test

Hydraulic compensator

Overview
Settings
Agg-Test

Net pump

Overview
Settings
Agg-Test

Zone valve

Overview
Status
Settings
Agg-Test

Ext. requirement

Overview
Settings

Additional boiler

Settings

9.12 Terms and definitions

In this chapter all parameters and terms of the different modules are explained.














Some terms can be a display value and a setting value. To recognize these, they are marked with a *.

- The term is a display value if aggregate test is inactive → the symbol of the aggregate test is: 
- If the aggregate test is active (by pressing the symbol  - the hand will change to green and the aggregate test gets activated) the individual components can be tested by pressing the control lamp. Now the term is a so-called setting value.

9.12.1 Boiler

Menu structure



Term	Description	Unit
Status I	<input type="radio"/> <input checked="" type="radio"/> <input type="radio"/>	
Boiler temperature	Indicates the boiler temperature	°C
Back flow temperature	Indicates the back flow temperature	°C
Boiler power	Indicates the boiler output	%
Back flow mixer	Indicates the actual state of the back flow mixer (OPEN/CLOSE)	-
Back flow pump	Indicates the actual state of the back flow pump (ON/OFF)	-
Status II	<input type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/>	
Flue gas temperature	Indicates the flue gas temperature	°C
Burning chamber temperature	Indicates the burning chamber temperature	°C
Stoker temperature	Indicates the stoker screw temperature (= feeding screw temperature)	°C
ID fan	Indicates the actual ID-fan power	%
Rotation speed	Indicates the actual ID-fan rotation speed	%
Status III	<input type="radio"/> <input type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/>	
ID fan correction	Indicates the actual ID-fan correction of the lambda probe control	%
Material correction	Indicates the actual material correction of the lambda probe control	%
Insertion - tact	Indicates the stoker screw (= feeding screw) interval (fuel gets fed to the burning chamber) ▪ Interval is set up by the customer service!	0,1 s
Insertion - pause	Indicates the stoker screw (= feeding screw) interval (fuel gets not fed to the burning chamber) ▪ Interval is set up by the customer service!	0,1 s
O2 [%]	Indicates the actual fuel gas O ₂ -content (oxygen content)	%
CO2 [%]	Indicates the actual fuel gas CO ₂ -content (carbon dioxide content)	%
Settings	<input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/>	
Residual heat temperature	Setting up the residual heat temperature (30-65) e.g.: minimum boiler temperature after fuel burnout, when (at the latest) return flow pump gets turned off	°C
Control hysteresis	Setting up the control hysteresis (3-20). It is a temperature, which exceeds regulated the required boiler temperature. ▪ Value gets set up by service staff!	°C
Minimum requirement	Setting up the minimal boiler set temperature (65-75) during operation	°C
Power max	Setting up the maximum boiler power (30-100). Enable boiler power regulation (limitation)	%
Fuel	Setting up predefined fuels (e.g.: pellets, wood chips, etc.)	-
Suction times	<input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/>	
Number of suction times	Setting up the number of suction times (maximal 5)	-
Time 1 / 2 / 3 / 4 / 5	Setting up the suction times per day	°C
Outputs I	<input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/>	
Grate cleaning*	Indicates the state of the grate cleaning ▪ If the indicator lamp lights up, the grate will be cleaned automatically	-

Term	Description	Unit
Boiler Stoker screw release	Indicates the state of the stoker screw <ul style="list-style-type: none"> If the indicator lamp lights up, the stoker screw is released by the software. If O₂-content is lower than 5 %, the stoker screw is blocked by the software. 	
Buffer Stoker screw*	Indicates the state of the stoker screw <ul style="list-style-type: none"> If the indicator lamp lights up, the fuel will be fed 	-
Hot water tank BFP open*	Indicates the state of the back burn flap (OPEN/CLOSE): <ul style="list-style-type: none"> If the indicator lamp lights up, the back burn flap is open The burn back protection prevents burn back in the fuel storage room. It separates additionally the combustion chamber and the fuel storage room. 	-
Discharge screw*	Indication of the state of the discharge screw (=room discharge). <ul style="list-style-type: none"> If the indicator lamp lights up, fuel is discharged from the storage room 	-
Heating circuit Container screw*	Indicates the status of the container screw. <ul style="list-style-type: none"> If the indicator lamp lights up, fuel is discharged from the container 	-
Pellets suction*	Indicates the status of the pellets suction. <ul style="list-style-type: none"> If the indicator lamp lights up, fuel is sucked from the fuel storage room 	-
Time mode Outputs II		
Lambda heating*	Indicates the status of the lambda probe heating. <ul style="list-style-type: none"> If the indicator lamp lights up, the lambda heating is active The lambda heating is in every operating mode (except "Heating off") active. 	-
Solar Heat exchanger cleaning*	Indicates the status of the heat exchanger cleaning. <ul style="list-style-type: none"> If the indicator lamp lights up, the heat exchanger is cleaned automatically. The interval while the heat exchanger is cleaned is adjusted by the customer service 	-
Hydraulic compensator Ignition heating*	Indicates the state of the ignition heating. <ul style="list-style-type: none"> If the indicator lamp lights up, the ignition heating gets activated and the fuel is ignited 	-
Net pump Ignition fan*	Indicates the status of the ignition fan: <ul style="list-style-type: none"> If the indicator lamp lights up, the fan gets activated (only at start-up) 	-
ID fan*	Indicates the ID-fan rotation speed and ID-fan excitation/control	%
Outputs III		
Zone valve Back flow pump*	Indicates the state of the back flow pump: <ul style="list-style-type: none"> If the indicator lamp lights up, the back flow pump is operating 	-
Back flow mixer open*	Indicates the state of the back flow mixer: <ul style="list-style-type: none"> If the indicator lamp lights up, the back flow mixer is open 	-
Back flow mixer close*	Indicates the state of the back flow mixer: <ul style="list-style-type: none"> If the indicator lamp lights up, the back flow mixer is closed 	-
Ext. requirement Output temperature control*	Indicates the state of the fuel storage room temperature control: <ul style="list-style-type: none"> If the indicator lamp lights up, the permissible fuel storage room temperature is exceeded 	-
Sum annoyance*	Indicates a common alarm	
Additional boiler module Operating alarm unit*	Indicates the boiler operation. If the indicator lamp lights up, the boiler is operating. <ul style="list-style-type: none"> If the operating condition "HEATING OFF" is active, the indicator lamp doesn't light up. 	-

Term	Description	Unit
Inputs I	<input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	
Grate closed	Indicates the state of the grate: <ul style="list-style-type: none"> If the indicator lamp lights up, the tipping grate is closed 	-
Tank empty	Indicates the state of the intermediate hopper: <ul style="list-style-type: none"> If the indicator lamp lights up, the intermediate hopper is empty 	-
BFP closed	Indicates the state of the burn back flap: <ul style="list-style-type: none"> If the indicator lamp lights up, the back burn flow protection is closed 	-
BFP open	Indicates the state of the burn back flap: <ul style="list-style-type: none"> If the indicator lamp lights up, the back burn flow protection is open 	-
STL	Indicates the state of the safety temperature limiter (STL): <ul style="list-style-type: none"> If the indicator lamp lights up, the safety temperature limiter is active, i.e.: the boiler turns off, if boiler temperature exceeds 95°C 	-
Temp. control storage room	Indicates the state of the storage room temperature control: <ul style="list-style-type: none"> If the indicator lamp lights up, the maximum storage room temperature is exceeded (the storage room temperature control sensor is active). 	-
Additional input	Indicates the state of the additional input: <ul style="list-style-type: none"> If the indicator lamp lights up, the additional input is active An additional input can be e.g. a CO-indicator, a system pressure control, etc. 	-
Inputs II	<input type="radio"/> <input checked="" type="radio"/> <input type="radio"/>	
Motor prot. discharge screw	Indicates the status of the stoker screw motor and the ash screw motor protection: <ul style="list-style-type: none"> If the indicator lamp lights up, the motor protection (stoker- or ash screw) has released 	-
Burner stop	Indicates the status of the boiler: <ul style="list-style-type: none"> If the indicator lamp lights up, the burner has stopped (digital input) 	-
Ash door opened	Indicates the status of the ash door: <ul style="list-style-type: none"> If the indicator lamp lights up, the ash door is opened 	-
Vacutrans flap opened	Indicates the status of the vacutrans flap: <ul style="list-style-type: none"> If the indicator lamp lights up, the vacutrans flap is opened 	-
Operating hours	<input type="radio"/> <input checked="" type="radio"/>	
Nominal load	Displays system operation hours during rated load phase	h
Modulation	Displays system operation hours during modulation phase	h
Part load	Displays system operation hours during part load phase	h
Scorch- /burn out	Displays system operation hours during burning, born down and burnout phase	h
Boiler run time	Displays the sum of nominal load-, modulation-, part load- and burn down- /burn out phase	h
Total	Displays total burner (incl. "HEATING OFF") hours	h

Boiler

Buffer

Hot water tank

Heating circuit

Time mode

Solar

Hydraulic separator

Net pump







Zone valve

Ext. requirement

Additional boiler module

9.12.2 Buffer







Menu structure



Term	Description	Unit
Status I ○ ● ○ ○ ○ ○ ○		
Buffer top temperature	Indicates the buffer top temperature	°C
Buffer middle temperature	Indicates the buffer middle temperature	°C
Buffer bottom temperature	Indicates the buffer bottom temperature	°C
Switching temperature	Indicates switching temperature (= average daytime temperature). In general the switching temperature conduces to switch between winter set temperature and summer set temperature.	°C
Outside temperature	Indicates the actual outside temperature	°C
Status II ○ ○ ● ○ ○ ○ ○		
Required temperature	Indicates the required temperature of the module. <ul style="list-style-type: none"> The required temperature is the sum of the winter/summer set temperature, temperature difference and temperature increase. (→ temperature manager, see chapter 8) 	°C
Buffer loading pump	Indicates the state of the buffer loading pump.	-
Fastrun heating	Indicates the state of the fastrun heating valve. <ul style="list-style-type: none"> The term is only visible, if "fastrun heating" is activated. If fastrun heating is active, the hot water tank upper zone gets heated up with the consumer's highest requested flow temperature (see chapter 8). So the requested flow temperature gets achieved quickly. 	-

9.12.3 Hot water tank

Menu structure



Term	Description	Unit
Overview	● ○ ○ ○ ○ ○ ○	
Fast start	Activates the fast start up (ON/OFF) If fast start up is activated, the hot water tank is heated independently (maximum loading time) to the requested set temperature.	-
Full-loading	Activates a full loading of the hot water tank (ON/OFF) If full-loading is activated, the hot water tank is heated up to the requested set temperature (→ only available, if second temperature sensor is installed)	-
Status	○ ● ○ ○ ○ ○ ○	
Hot water tank temperature	Indicates the hot water tank upper zone temperature	°C
Loading valve	Indicates the state of the loading valve (→ only visible, if hot water tank pump is activated)	-
Hot water tank pump	Indicates the state of the hot water tank pump (→ only visible, if loading valve is inactivated)	-
Hot water tank temperature bottom	Indicates the hot water tank bottom zone temperature (→ only visible, if second temperature sensor is installed)	°C
Load-through valve	Indicates the state of the load-through valve (→ only visible, if load-through valve is activated and a heat pump is installed)	-
Circulation temperature	Indicates the circulation temperature (→ only visible, if circulation pump is activated)	°C
Circulation pump	Indicates the state of the circulation pump (→ only visible, if circulation pump is activated)	-
Settings	○ ○ ● ○ ○ ○ ○	
Must temperature	Setting up the hot water tank set temperature (50-85)	°C
Min. loading / temperature	Indicates/activates the min. loading / temperature (20-55) (ON/OFF) <ul style="list-style-type: none"> ▪ If the hot water tank min. loading / temperature is activated and the state out of max loading time, the hot water tank temperature will be set equal to min. loading / temperature. ▪ If hot water tank temperature is lower than the min. loading / temperature value, the hot water tank loading will start 	°C
Temp. increase	Setting up an increase (0-15) of the required hot water tank temperature <ul style="list-style-type: none"> ▪ Compensates heat loss by exceeding the hot water tank set temperature 	°C
Max. Loading time	Setting up maximum hot water tank loading time (0-10), when hot water tank is loaded to hot water tank set temperature	h
Legio temperature	Setting up the legionella temperature (0-95) <ul style="list-style-type: none"> ▪ Hot water tank will be heated up, within the given hot water tank loading time, to the legionella temperature weekly to kill bacteria. ▪ A deactivation of this parameter is done by setting up the legionella temperature to 0 °C. 	°C
Circulation pump	Activates the circulation pump (ON/OFF) <ul style="list-style-type: none"> ▪ During the hot water tank loading time the circulation pump is switched on 2 minutes for every 10 minutes ▪ If circulation pump is activated, „circulation pump“ is available at the agg-test- 	-
Loading valve	Activates the loading valve (ON/OFF) <ul style="list-style-type: none"> ▪ If loading valve is activated, „loading valve“ is available at the agg-test (→ only if loading valve is installed) 	-

Boiler

Buffer

Hot water tank

Heating circuit

Time mode

Solar


Hydraulic separator

Net pump

Zone valve

Ext. requirement

Additional boiler module

Term	Description	Unit
Time program		
Time 1	Three different time options are available: <ul style="list-style-type: none"> time 1: 08:00 – 10:00 time 2: 15:00 – 21:00 time 3: 00:00 – 00:00 	-
08:00 – 11:00	Setting up individual hot water tank loading times of every weekday	-
	Monday preset gets assigned to remaining weekdays	-
Circulation time		
Time 1	Two different time options are available: <ul style="list-style-type: none"> time 1: 08:00 – 10:00 time 2: 15:00 – 21:00 	-
08:00 – 11:00	Setting up individual circulation times of every weekday.	-
	Monday preset gets assigned to remaining weekdays	-
Agg-Test		
Hot water tank pump*	Indicates the state of the hot water tank pump: <ul style="list-style-type: none"> If the indicator lamp lights up, the hot water tank pump is running Only visible, if "loading valve" is not activated 	-
Loading valve*	Indicates the state of the loading valve: <ul style="list-style-type: none"> If the indicator lamp lights up, the loading valve is open Only visible, if "loading valve" is activated 	-
Load-through valve*	Indicates the state of the load-through valve: <ul style="list-style-type: none"> If the indicator lamp lights up, the load-through valve is open and the hot water tank is loaded faster (= fast start) Only visible, if "loading valve" is activated 	-
Circulation pump*	Indicates the state of the circulation pump: <ul style="list-style-type: none"> If the indicator lamp lights up, the circulation pump is running Only visible, if "circulation pump" is activated 	-

9.12.4 Heating circuit

Menu structure

Overview

Status I

- Flow temperature
- Back flow temperature
- Outside temperature
- Room temperature
- Room correction

Status II

- Switching temperature
- Heating circuit mixer
- Heating circuit pump
- Screed days

Operation modes

- Heating circuit
 - Heating time mode
 - Durable heat
 - Durable kneeling
 - Flow fixed
 - Remote control
 - Screed drying
- Actual heating circuit mode
- Remote control number
- Balancing room sensor
- Kneeling barrier

Parameter I

- Room set temperature
- Kneeling temperature
- Flow fixed temperature
- Room influence
- Correction
- Kneeling influence
- End run

Parameter II

- Switching temperature
- Temp. increase
- Outside temp. sensor
- Balancing outside sensor
- Hot water tank priority
- Kneeling barrier

Heat curve

Heat curve settings

- Flow max. temperature
- Root point temperature
- Flow temperature at +10°C
- Flow at adjustable outside temp.
- Adjustable outside temperature
- Actual outside temperature
- Switch off temperature

Time program

Time

Agg-Test

- Heating circuit pump
- Heating circuit mixer OPEN
- Heating circuit mixer CLOSE

Boiler
Buffer
Hot water tank
Heating circuit
Time mode
Solar
Hydraulic
Net pump
Zone valve
Ext. requirement
Additional boiler module

Term	Description	Unit
Status I ○ ● ○ ○ ○ ○ ○ ○ ○ ○ ○		
Flow temperature	Indicates the flow temperature of chosen heating circuit	°C
Back flow temperature	Indicates the back flow temperature of chosen heating circuit	°C
Outside temperature	Indicates the actual outside temperature	°C
Room temperature	Indicates the room temperature	°C
Room correction	Indicates the room correction	°C
Status II ○ ○ ● ○ ○ ○ ○ ○ ○ ○ ○		
Switching temperature	Indicates the switching temperature (= average daytime temperature). In general the switching temperature conducts the switching between winter set temperature and summer set temperature.	°C
Heating circuit mixer	Indicates the state of the heating circuit mixer (OPEN/CLOSE)	-
Heating circuit pump	Indicates the state of the heating circuit pump (ON/OFF)	-
Screed days	Setting up screed drying heat day ▪ Only visible, if operation mode "screed drying" is activated	-
Operation modes ○ ○ ○ ● ○ ○ ○ ○ ○ ○ ○		
Heating circuit	Activation heating circuit (ON/OFF)	-
Operation modes	Selection operation modes: ▪ Heating time mode: Heating corresponds to the set heating time ▪ Durable heat: Constant heat up to required set room temperature or to the calculated feed flow target temperature ▪ Durable kneeling: Constant heat up to setback temperature respectively calculated flow temperature during setback time ▪ Flow fixed: A defined feed flow set temperature will be held constantly during the set heating time. ▪ Remote control: Modus corresponds to the remote control setting. Only available, if remote control is connected. ▪ Screed drying: Modus of screed drying. The operation of the screed drying is described on page 39 .	-
Actual heating circuit mode	Indicates the actual heating circuit operating mode	-
Remote control number	Selection of heating circuit's remote control	-
Balancing room sensor	Setting up balancing room sensor (-5 to +5)	°C
Kneeling barrier over room temperature	Activates the kneeling barrier (ON/OFF) → only possible with remote control: ▪ If actual room temperature is higher then set room temperature, the option „ Kneeling barrier over room temperature“ provides a lock of the heating circuit.	-
Parameter I ○ ○ ○ ○ ● ○ ○ ○ ○ ○ ○		
Room must temperature	Setting up the required room temperature during heating time. This setting is only used in connection with a remote control (FBR 1)	°C
Kneeling temperature	Setting up required room temperature during lowering time.	°C

Term	Description	Unit
Flow fixed temperature	Setting up the flow temperature (20 to maximum flow set temperature) during the set heating time (operation mode "flow fixed")	°C
Room influence	Room influence (0-10) influences the flow temperature as a function of the room temperature: <ul style="list-style-type: none"> Depending on the level of this value (0-10), the difference of required room- and room set temperature exerts more influence on the calculation of the flow set temperature. 	-
Correction	The correction influences respectively adjust the flow set temperature: <ul style="list-style-type: none"> This value (-5 to +5) gets multiplied by 2 and added to the flow set temperature 	°C
Kneeling influence	Setting up the factor (0-10) of the lowering temperature influence	-
End run	Setting up the outside temperature (-25 to 10) which conducts a permanent running of the pump to avoid freezing.	°C
Parameter II	<input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/> <input type="radio"/>	
Switching temperature	Setting up the switching temperature (10-35). That's the average daytime temperature that conducts the switching between winter set temperature and summer set temperature. A higher level of the switching temperature will delay the switching to summer operation.	°C
Temp. increase	Setting up an increase (0-15) of the required heat circuit temperature. Compensates heat loss between buffer and heat circuit by exceeding the hot water tank set temperature. High heat loss assumes a higher value.	°C
Outside temp. sensor	Selection of the outside temperature sensor <ul style="list-style-type: none"> If multiple outside temperature sensors are installed, the desired one can be assigned to the chosen heat circuit. 	-
Balancing outside sensor	Adjusting the balancing of the outside temperature sensor <ul style="list-style-type: none"> Adjustment with a reference thermometer (actual outside temperature) 	°C
Hot water tank priority	Activation hot water tank priority (ON/OFF) <ul style="list-style-type: none"> The hot water tank is loaded prior compared to the heating circuit. 	-
Kneeling barrier	Activation kneeling barrier (ON/OFF) <ul style="list-style-type: none"> Heating circuit gets locked during permanent reduction respectively beyond heating time 	-
Heat curve settings	<input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	
Flow max. temperature	Setting up the maximum flow temperature (30-95) of chosen heating circuit	°C
Root point temperature	Setting up the minimum flow temperature (20-70) of chosen heating circuit	°C
Flow temperature at +10°C	Setting up the flow temperature (20-90) of chosen heating circuit at +10°C outside temperature	°C
Flow at adjustable outside temperature	Setting up the flow temperature (25-95) of chosen heating circuit at a adjustable outside temperature	°C
Adjustable outside temperature	Setting up the outside temperature (-20 to -10) of chosen heating circuit regarding flow set temperature	°C
Actual outside temperature	Indicates the actual outside temperature	°C
Switch off temperature	Setting up the outside temperature (10-40) regarding deactivation of chosen heating circuit	°C

Boiler

Buffer

Hot water tank

Heating circuit

Time mode

Solar

Hydraulic separator

Net pump

Zone valve

Ext. requirement

Additional boiler module

Term	Description	Unit
Time program		
Time 1	Three different time options are available: <ul style="list-style-type: none"> time 1: 08:00 – 10:00 time 2: 15:00 – 21:00 time 3: 00:00 – 00:00 	-
08:00 – 11:00	Setting up individual hot water tank loading times of every weekday	-
	Monday preset gets assigned to remaining weekdays	-
Agg-Test		
Heating circuit pump*	Indicates the state of the heating circuit pump: <ul style="list-style-type: none"> If the indicator lamp lights up, the heating circuit pump is running 	-
Heating circuit mixer OPEN*	Indicates the state of the heating circuit mixer: <ul style="list-style-type: none"> If the indicator lamp lights up, the heating circuit mixer is open 	-
Heating circuit mixer CLOSE*	Indicates the state of the heating circuit mixer: <ul style="list-style-type: none"> If the indicator lamp lights up, the heating circuit mixer is closed 	-

Operation mode „Screed drying“

After „Screed drying“ mode selection the shown flow temperature sequence (see figure 9.17) gets started immediately. If a lower flow temperature is desired, the flow temperature can be set up with the parameter „Flow max. temperature“. If screed drying is interrupted caused by a fault (power breakdown, etc.), the program (after fault correction) continues drying as shown in Table 9.1 automatically. An optional continuing day can be selected with parameter „Screed days“. After screed drying completion the boiler will switch to "heating time mode".

Table 9.1: Operation mode „Screed drying“

Bake out day	Flow set temperature in °C
1	25
2	30
3	35
4	40
5 – 12	45
13	40
14	35
15	30
16	25
17 – 23	10
24	30
25	35
26	40
27	45
28	35
29	25

If screed drying gets interrupted, resume drying as follows:	
Day of interruption	resume from day
0 – 15	1
16	16
17 – 23	17
24 – 28	24
29	29




figure 9.17: Flow set temperature as a function of bake out days at „Screed drying“

Boiler
Buffer
Hot water tank
Heating circuit
Time mode
Solar
Hydraulic compensator
Net pump
Zone valve
Ext. requirement
Additional boiler module

9.12.5 Time mode

Menu structure

Time program
● ○
Time


Settings
○ ●
Time requirement

Term	Description	Unit
Time program	● ○	
Time 1	Three different time options are available: <ul style="list-style-type: none"> ▪ time 1: 08:00 – 10:00 ▪ time 2: 15:00 – 21:00 ▪ time 3: 00:00 – 00:00 	-
08:00 – 11:00	Setting up individual hot water tank loading times of every weekday	-
	Monday preset gets assigned to remaining weekdays	-
Settings	○ ●	
Time requirement	If the boiler works only as a heat supplier (no heating circuit installed), the set up boiler set temperature (20-100) gets supplied during the set heating times.	°C

9.12.6 Solar

NOTE: At the solar module 5 resp. 6 (only at external solar module) program numbers are available, which are set up by the service technician. The only differences of the programs are the integration and the number of tanks (e.g. hot water tank, buffer). The hydraulic schemes of the different modules are described in appendix 14.2

Menu structure




<p>Overview</p> 	<p>Status I</p> <ul style="list-style-type: none"> Collector flow temperature Collector back flow temperature Tank 1 temperature Tank 2 temperature 	<p>Status II</p> <ul style="list-style-type: none"> Actual yield Daily yield Total yield Collector pump Loading pump Switching valve
<p>Settings I</p> <ul style="list-style-type: none"> Program number Antifreeze Flow rate Rotation speed control Min. rotation speed Must value Control difference 	<p>Settings II</p> <ul style="list-style-type: none"> Pump trigger Tank 1 must temperature Difference 1 Tank 1 max. temperature Tank 2 must temperature Difference 2 Tank 2 max. temperature 	<p>Agg-Test</p> <ul style="list-style-type: none"> Collector pump Loading pump Switching valve OPEN Switching valve CLOSE

Term	Description	Unit
Status I ○ ● ○ ○ ○ ○ ○		
Collector flow temperature	Indicates the collector flow temperature	°C
Collector back flow temperature	Indicates the collector backflow temperature	°C
Tank 1 temperature	Indicates the temperature of tank 1 (e.g.: hot water tank, buffer)	°C
Tank 2 temperature	Indicates the temperature of tank 2 (e.g.: hot water tank, buffer) (only visible, if program 3, 4, 5 or 6 is chosen)	°C
Status II ○ ○ ● ○ ○ ○ ○		
Actual yield	Indicates actual energy yield	W
Daily yield	Indicates daily energy yield (0 – 24h)	Wh
Total yield	Indicates total measured energy yield	kWh
Collector pump	Indicates the state of the collector pump	-
Loading pump	Indicates the state of the loading pump ▪ only visible, if program number 2 or 6 is chosen	-
Switching valve	Indicates the state of the switching valve ▪ only visible, if program number 3, 4, 5 or 6 is chosen	-

Term	Description	Unit
Settings I ○ ○ ○ ● ○ ○		
Program number	Indicates the program number (1 to 6)	-
Antifreeze	Setting up the minimum outside temperature (-45 to 5), which conducts a permanent running of the solar pump to avoid freezing.	°C
Flow rate	Setting up the flow rate (0-99,9) for calculating of solar output respectively the yield	l/min
Rotation speed control	Setting up the rotation speed control (ON/OFF)	-
Min. rotation speed	Setting up the minimum solar pump rotation speed (20-100)	%
Must value	Setting up the solar pump rotation speed set point	°C
Control difference	Setting up the rotation speed control difference (if active)	°C
Settings II ○ ○ ○ ○ ● ○		
Pump trigger	Setting up the minimum collector temperature (15-70) to startup the solar pump	°C
Tank 1 must temperature	Setting up the set temperature (25-90) of tank 1	°C
Difference 1	Setting up the collector difference (5-30) of tank 1	°C
Tank 1 max. temperature	Setting up the maximum temperature (25-95) of tank 1	°C
Tank 2 must temperature	Setting up the set temperature (25-90) of tank 1 (→ only visible, if program number 3, 4, 5 or 6 is chosen)	°C
Difference 2	Setting up the difference (5-30) between collector and tank 1 (→ only visible, if program number 3, 4, 5 or 6 is chosen)	°C
Tank 2 max. temperature	Setting up the maximum tank temperature (25-95) of tank 1 (→ only visible, if program number 3, 4, 5 or 6 is chosen)	°C
Agg-Test ○ ○ ○ ○ ○ ●		
Collector pump*	Indicates the status of the collector pump: ▪ If the indicator lamp lights up, the collector pump is running	-
Loading pump*	Indicates the state of the loading pump (→ only visible, if program number 2 or 6 is chosen) ▪ If the indicator lamp lights up, the loading pump is running	-
Switching valve OPEN*	Indicates the state of the switching valve (→ only visible, if program number 3, 4, 5 or 6 is chosen) ▪ If the indicator lamp lights up, the switching valve is open	-
Switching valve CLOSE*	Indicates the state of the switching valve (→ only visible, if program number 3, 4, 5 or 6 is chosen) ▪ If the indicator lamp lights up, the switching valve is closed	-

9.12.7 Hydraulic compensator module




Menu structure



Term	Description	Unit
Status ○ ● ○ ○		
Hydr. compensator temperature	Indicates the hydraulic compensator temperature <ul style="list-style-type: none"> The hydraulic compensator has a built in temperature sensor 	°C
Existing temperature	Indicates the flow temperature of the upstream module (e.g.: boiler, buffer)	°C
Required temperature	Indicates the required temperature of the downstream module (e.g. heating circuit)	°C
Pump 1	Indicates the state of pump 1 (ON/OFF) <ul style="list-style-type: none"> Pump 1 is the pump in the back flow on the primary side 	-
Pump 2	Indicates the state of pump 2 (ON/OFF) <ul style="list-style-type: none"> Pump 2 is the pump in the flow on the secondary side 	-
Settings ○ ○ ● ○		
Switch on barrier	Setting up the switch on barrier of pump 2: <ul style="list-style-type: none"> If the flow temperature of the upstream module (e.g. boiler, buffer) is higher than the set up "switch on barrier", pump 2 is turned on otherwise pump 2 will stay switched off. 	°C
Temp. increase	Setting up the temperature increase of the required temperature <ul style="list-style-type: none"> Compensates heat loss by exceeding the downstream module temperature requirement. 	°C
Agg-Test ○ ○ ○ ●		
Pump 1*	Indicates the state of pump 1: <ul style="list-style-type: none"> Pump 1 is the pump in the back flow on the primary side If the indicator lamp lights up, pump 1 is switched on 	-
Pump 2*	Indicates the state of pump 2: <ul style="list-style-type: none"> Pump 2 is the pump in the flow on the secondary side If the indicator lamp lights up, pump 2 is switched on 	-

9.12.8 Net pump




Menu structure



Term	Description	Unit
Status ○ ● ○ ○		
Existing temperature	Indicates the temperature of the upstream module (e.g.: buffer top temperature)	°C
Required temperature	Indicates the required temperature of the downstream module (e.g.: buffer) <ul style="list-style-type: none"> Indicates the required temperature of the downstream module (e.g. buffer) 	°C
Pump	Indicates the state of the net pump	-
Settings ○ ○ ● ○		
Switch on barrier	Setting up the switch on barrier for the net pump: <ul style="list-style-type: none"> If the flow temperature of the upstream module (e.g. boiler, buffer) is higher than the set up "switch on barrier", net pump is turned on otherwise the net pump will stay switched off. 	°C
Temp. increase	Setting up the temperature increase of the required temperature <ul style="list-style-type: none"> Compensates heat loss by exceeding the downstream module temperature requirement. 	°C
Agg-Test ○ ○ ○ ●		
Pump*	Indicates the state of the net pump: <ul style="list-style-type: none"> If the indicator lamp lights up, the net pump is switched on 	-

9.12.9 Zone valve

Menu structure



Term	Description	Unit
Status	○ ● ○ ○	
Existing temperature	Indicates downstream module temperature (e.g.: buffer top temperature)	°C
Required temperature	Indicates the required temperature of the downstream module (e.g.: buffer) <ul style="list-style-type: none"> Indicates the required temperature of the downstream module (e.g. buffer) 	°C
Zone valve	Indicates the state of the zone valve	-
Settings	○ ○ ● ○	
Switch on barrier	Setting up the switch on barrier of the zone valve: <ul style="list-style-type: none"> If the flow temperature of the upstream module (e.g. boiler, buffer) is higher than the set up "switch on barrier", the zone valve is opened otherwise the zone valve will stay closed. 	°C
Temp. increase	Setting up the temperature increase of the required temperature <ul style="list-style-type: none"> Compensates heat loss by exceeding the downstream module temperature requirement. 	°C
Agg-Test	○ ○ ○ ●	
Zone valve OPEN*	Indicates the state of the zone valve: <ul style="list-style-type: none"> If the indicator lamp lights up, the zone valve is opened 	-

9.12.10 External demand

The external requirement module provides an interface to an external foreign control loop (e.g. central building control system). The requirement, which can be digital or analogue, is registered as a required temperature (e.g. boiler must temperature by the boiler or buffer top temperature by the buffer) in the heat supplier (e.g. boiler or buffer).

Menu structure

Overview	Status	Settings
● ○ ○	○ ● ○	○ ○ ●
External demand Analogue must temperature	Demand active Analogue must Analogue must	External must temperature Analogue must active Analogue must temperature 4 mA Analogue must temperature 20 mA Analogue must temperature Max. Analogue must temperature Min. Line monitoring

Term	Description	Unit
Overview	● ○ ○	
External demand	Indicates a digital input signal of the external control loop (requirement): <ul style="list-style-type: none"> If the indicator lamp lights up, the external control loop sends a requirement to the digital input 	-
Analogue must temperature	Indicates the actual analogue set temperature	°C
Status	○ ● ○	
Demand active	Indicates the state of the external demand	-
Analogue must	Indicates the actual analogue set temperature	°C
Analogue must	Indicates the actual analogue set temperature <ul style="list-style-type: none"> The analogue set temperature gets inverted by calculation in compliance with Ohm's law into a voltage (see figure 9.18) 	mV
Settings	○ ○ ●	
External must temperature	Setting up the (digital) external set temperature: <ul style="list-style-type: none"> The boiler will operate with the external set temperature (fixedly) as long as the analogue set temperature does not exceed the set up temperature 	°C
Analogue must active	Activates the analogues set point setting	-
Analogue must temperature 4 mA	Setting up lower limit of analogue set temperature at 4 mA (see figure 9.18). <ul style="list-style-type: none"> If input is a analogue signal of 4 mA, the boiler operates with the set up temperature 	°C
Analogue must temperature 20 mA	Setting up upper limit of analogue set temperature at 20 mA (see figure 9.18). <ul style="list-style-type: none"> If input is a analogue signal of 20 mA, the boiler operates with the set up temperature 	°C
Analogue must temperature Max.	Setting up maximum analogue set temperature	°C
Analogue must temperature Min.	Setting up minimum analogue set temperature	°C
Line monitoring	Activates the line monitoring (ON/OFF)	

External requirement at digital input:

At a digital request the external set temperature gets transmitted as value to the heat supplier.

External requirement at analogue input

At an analogue request a calculated (= linearly interpolated) temperature gets transmitted to the heat supplier (see figure 9.18). The graph in figure 9.18 gets regulated by the parameters „analogue must temperature 4 mA“ and „analogue must temperature 20 mA“.

For example at an analogue request with an current signal of 12 mA, a temperature of 60 °C is registered at the heat supplier, provided that the digital requirement (= external must temperature) is not higher.




figure 9.18: Analogue set temperature as a function of the applied current signal of the external requirement

At the input of the external requirement module a current signal between 4 and 20 mA should be given, because a current signal is compared to a voltage signal insensitive to electromagnetic disturbances and voltage losses at the cables. With an internal resistor (500 Ohm) the current signal is converted into a voltage signal.




figure 9.19: Input signal of the external requirement module

9.12.11 Additional boiler

The recommended hydraulic schemes are shown in appendix 14.1.

Menu structure

Overview
<ul style="list-style-type: none"> ● Boiler type Waiting period Pump trigger Pump difference Pump after run Flue gas min. temperature Boiler min. temperature Minimum requirement Control hysteresis

Term	Description	Unit
Settings		
Boiler type	Selection boiler type: <ul style="list-style-type: none"> ▪ Automatic: If using automatic additional boilers (e.g.: oil-boiler) ▪ Manually: If using lock wood boilers ▪ Oil burner: burner control 	-
Waiting period	<ul style="list-style-type: none"> ▪ Automatic / Oil burner: additional boiler waiting time (if required) ▪ Manually: additional boiler minimum operation time till additional boiler is available again 	-
Pump trigger	Setting up pump trigger	-
Pump difference	Setting up pump turn off difference	-
Pump after run	Setting up additional boiler stopping time	-
Flue gas min. temperature	Setting up flue gas minimum temperature (→ only visible, if manual was chosen):	-
Boiler min. temperature	Setting up boiler minimum temperature (→ only visible, if manual was chosen): If this boiler temperature is exceeded, additional boiler will get active (0 °C = no monitoring)	-
Minimum requirement	Setting up minimum requirement (→ only visible, if burner was chosen) If this minimum additional boiler temperature is exceeded, the additional boiler will supply heat	-
Control hysteresis	Setting up control hysteresis (→ only visible, if burner was chosen) If additional boiler temperature exceeds required additional boiler temperature + control hysteresis, the additional boiler will be turned off.	-

9.13 Menu settings

Navigation:  →  → →111 → OK

Screen:





figure 9.20: Overview menu settings

If touching symbol:

	the network configuration will be displayed. (see chapter 9.13.1 – page 50)
	the Modbus – settings will be displayed. (see chapter 9.13.2 – page 51)
	the screensaver settings will be displayed. (see chapter 9.13.3 – page 52)
	information such as software version operating system number,... will be displayed. (see chapter 9.13.4 – page 52)
	messages by E-mail can be send (see chapter 9.13.5 – page 53)
	E-mail times setting will be displayed (when an E-mail has to be sent) (see chapter 9.13.6 – page 55)
	the mail server settings will be displayed. (see chapter 9.13.7 – page 56)

9.13.1 Network configuration

Navigation 1: 	Navigation 2: 		
Screen: 	Screen: 		
figure 9.21: Network configuration	figure 9.22: DNS settings		
If the following field is pressed:			
NetBIOS Name	the NetBIOS name can be set up	DNS 1 / DNS 2	the IP address of the DNS server can be set up
IP-Address	The boiler IP address can be set up		the network configuration page will be displayed again (see figure 9.21)
Subnetmaske	the subnet mask can be set up		
Gateway-Address	the gateway address can be set up		
	the settings can be saved		
	the submenu for the DNS settings will be displayed (see figure 9.22)		
	The menu settings will be displayed again	Note:	
		DNS means D omain N ame S ystem which unpacks a domain into the corresponding IP address. That means, by setting up the DNS server, the T CONTROL is able to send E-mails. <u>We recommend the following configuration:</u> DNS 1: 8.8.8.8 (= DNS Server of Google, it is public and free. That can be an alternative to the internet provider's server) DNS 2: DNS – Server of the internet provider	

9.13.2 Modbus – settings

Navigation: 

Screen:




figure 9.23: Modbus – settings

If the following field is pressed:

Port	Setting up the TCP port number. 502 is reserved for Modbus-TCP.
Timeout	Setting up the time delay of the data transfer
RX / TX Buffer	Setting up the buffer size in byte
max. values	Setting up the maximum values of the servers.
Accept Changes	Save changes
	the network configuration page will be displayed again.

Note:

Modbus is an application protocol to exchange messages between intelligent Modbus controllers in the building management system. The Modbus protocol “TCP” is used in the HERZ control. This protocol transmits the encoded data via LAN cable. Modbus ensures that connected controllers in the building management system receive the transmitted data from the boiler, so they can continue processing.

9.13.3 Screensaver

Navigation: 

Screen:



figure 9.24: Screensaver

If the following field is pressed:

1	the screensaver gets activated / deactivated.
2	the screen saver waiting time can be set up.
3	the screensaver standby mode gets activated / deactivated.
4	the standby mode waiting time can be set up
	the menu settings will be displayed again

9.13.4 Information overview

Navigation: 

Screen:



```

>>>>> AKTUELLE KONFIGURATION / ACTUAL CONFIGURATION <<<<<<
-----
MODULTYPE           ||STNR|MODN|LIEF| HW |USER| SW |CPU |
-----
KESSEL / BOILER     ||000 |001 |000 |0010|XXXX|XXXX|0500|
PUFFER / BUFFER     ||004 |068 |000 |0010|0002|0021|0300|
ZUSATZKESSEL / ADD. BOILER||003 |072 |000 |0016|0001|0000|0210|
ZEITBETRIEB / TIME MODE ||000 |133 |068 |XXXX|XXXX|XXXX|XXXX|
-----
SOFTWARE: 01.10
OSSYSTEM: 01.02.251
FIRMWARE: 1.8
  
```

figure 9.25: Information overview

Note:

The information shows an overview of the current software versions, operating system, firmware and also the hydraulic scheme. If a USB-Stick is plugged in, the hydraulic scheme can be saved. No values can be changed.

9.13.5 Sending E-mails

ACTIVATE E-MAIL DISPATCH	CREATE RECEIVER LIST
---------------------------------	-----------------------------

Navigation 1:	Navigation 2: → receiver list
----------------------	--------------------------------------



figure 9.26: Mail Settings




figure 9.27: Mail receiver list

If the following field is pressed:		If the following field is pressed:	
receiver list	the E-mail receiver list gets displayed (see figure 9.27)	beispiel@mail-server.com	the receiver's E-mail addresses can be set up
E-Mail subject	The E-mail subject can be set up.	add	the entered E-mail address gets added to the receiver list
	E-Mail dispatch can be activated / deactivated.	clear	the selected E-mail address gets deleted off the receiver list
	the menu settings will be displayed again	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	several values (errors, warnings, info) can be chosen.
			the selected E-mail address and values (error, warnings, info) are saved.
			the mail settings will be displayed again (see figure 9.26).
Note:			
Selection:		<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> 1 2 3 4	
1	If the box is not checked, no E-mail will be sent to the recipient.		
2	If the box is checked, errors will be transmitted		
3	If the box is checked, warnings will be transmitted		
4	If the box is checked, information will be transmitted		

MAIL SUBJECT	TEST-MAIL SENDING
---------------------	--------------------------

Navigation:	 → Subject	Navigation:	
Screen: 		Screen: 	
<p style="text-align: center;">figure 9.28: Mail subject</p>		<p style="text-align: center;">figure 9.29: Test-Mail sending</p>	
If the following field is pressed:		If the following field is pressed:	
	the entry will be confirmed.	Test-mail send	Send E-mail to recipient. (only visible/possible if sending is active)
	the last character will be deleted.		
	characters will be written in uppercase		

9.13.6 E-Mail status report

Navigation: 

Screen:

Mail - status report

Number of times	5	1
Time 1	09:00	2
Time 2	14:00	3
Time 3	16:00	4
Time 4	20:00	5
Time 5	22:00	6



figure 9.30: E-Mail status report

If the following field is pressed:

1	the quantity of times (maximum 5) can be set up
2-6	individual sending times (error, warning, information → see figure 9.27) can be set up.
	The menu settings will be displayed again

9.13.7 Server settings

Navigation: 

Screen:



figure 9.31: Server settings

If the following field is pressed:

smtp.1und1.de	the mail server address can be entered (=outgoing mail server)
touch@herz-energie.at	the boiler's E-mail address can be entered
Password	the password can be entered
touch@herz-energie.at	the username can be entered
SSL	the encoding can be chosen (no, SSL, TLS)

Note:

To send mail at the adjusted values (error, warning, information according to 1057), the boiler has to have a valid E-mail address. After the successful creation of an E-mail address you can set up the exemplified values shown in figure 9.31.

Look up the data of the mail server and the port number at your provider (for example GMX).

After successful configuration of the mail server settings the boiler will send E-mail with the set up values

10 FAULT REPORTS AND THEIR CORRECTIONS

	You should always take particular note of the safety instructions! (see chapter 1)
	If a fault arises, the fault must always be rectified first and afterwards cleared by switching the system on again. If several faults arise at the same time, they will be displayed in order of their occurrence.

	010	020	030	040	050	060		080	090	180
001	011	021	031	041	051	061	071	081		181
002	012	022	032	042		062	072	082		182
003	013	023	033	043	053	063	073	083	093	
004	014	024	034	044	054	064		084		
005	015	025	035	045	055	065		085	095	
006	016	026	036	046	056	066	076	086	096	
007	017	027	037	047	057	067	077	087		
008	018	028	038	048	058	068	078			
009	019	029	039	049	059	069	079			189

I	Info / indication	
W	Warning	
F	Fault; error / component failure; control failure; malfunction	

No.	Fault report	Cause of fault	Fault correction
-----	--------------	----------------	------------------

No.	Fault report	Cause of fault	Fault correction
001	BOILER SENSOR	Failure boiler temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
002	COMBUSTION ROOM SENSOR	Failure burning chamber temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
003	FLUE GAS SENSOR	Failure flue gas temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
004	BACK FLOW SENSOR	Failure back flow temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
005	STOKER SENSOR	Failure feeding screw temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
006	BOILER-OUTSIDE SENSOR	Failure boiler outside temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
007	BUFFER SENSOR TOP	Failure buffer top temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
008	BUFFER SENSOR BOTTOM	Failure buffer bottom temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party

No.	Fault report	Cause of fault	Fault correction
009	BUFFER SENSOR OUTSIDE TEMP.	Failure buffer outside temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
010	BUFFER SENSOR MIDDLE	Failure buffer centre temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
011	HOT WATER TANK SENSOR	Failure hot water tank temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
012	CIRCULATION SENSOR	Failure circulation temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
013	HC-FLOW SENSOR	Failure heating circuit flow temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
014	HC-BACK FLOW SENSOR	Failure heating circuit back flow temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
015	HC-ROOM SENSOR	Failure room temperature remote control (FBR1)	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
016	HC-ROOM CORR.	Failure room temperature remote control (FBR1)	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party

No.	Fault report	Cause of fault	Fault correction
017	HC-OUTSIDE SENSOR	Failure heating circuit outside temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
018	SENSOR COLLECTOR	Failure solar collector temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
019	SENSOR COLLECTOR BACK FLOW	Failure solar collector back flow temperature sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
020	SENSOR SOLAR TANK 1	Failure solar tank 1 temperature sensor (hot water tank/buffer)	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
021	SENSOR SOLAR TANK 2	Failure solar tank 2 temperature sensor (hot water tank/buffer)	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
022	SENSOR SOLAR RES.	Failure reserve solar sensor	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
023	ADDITIONAL BOILER SENSOR	Failure additional boiler sensor; cable break; short-circuit; failure connection	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party
024	HYDR. COMP. SENSOR	Failure hydraulic compensator temperature sensor; cable break; short-circuit; failure connection	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary ▪ ☎ - contracting party

No.	Fault report	Cause of fault	Fault correction
025	OVERHEAT	Boiler temperature exceeded 92 °C	<ul style="list-style-type: none"> ▪ Check settings ▪ Check back flow mixer ▪ Check back flow pump
026	OVERHEAT BOILER MAX	Boiler temperature exceeded 98 °C	<ul style="list-style-type: none"> ▪ Check settings ▪ Check back flow mixer ▪ Check back flow pump
027	SOLAR OVERHEATING	Fault is shown, if collector temperature exceeds 140 °C	<ul style="list-style-type: none"> ▪ Check solar pump ▪ Check solar tank level
028	SOLAR MAX. LOADING	Collector temperature exceeds 120 °C	-
029	ANTIFREEZE BOILER	Boiler temperature respectively operation room temperature under 7 °C	-
030	ANTIFREEZE BUFFER	Buffer bottom sensor temperature under 7 °C	-
031	ANTIFREEZE HOT WATER TANK	Hot water tank under 7 °C	-
032	ANTIFREEZE HEATING CIRCUIT	Heating circuit- or heating circuit back flow temperature under 7 °C	-
033	ANTIFREEZE SOLAR	Collector temperature under set up antifreeze temperature	-
034	ANTIFREEZE HYDR. COMPENSATOR	Hydraulic compensator temperature under 7 °C	-
035	ANTIBLOCKING BACK FLOW	Back flow antiblocking active, back flow pump gets triggered 10 seconds	-
036	ANTIFR. ADD. BOILER	Additional boiler temperature under 7 °C	-
037	HOT WATER TANK LOADING	Hot water tank didn't reach set temperature during loading time; hot water tank loading gets blocked till fault correction	<ul style="list-style-type: none"> ▪ Adapt loading time ▪ Activate hot water tank priority ▪ Hot water tank settings (min. / set)
038	MAINTENANCE	This fault text occurs after 1000 operating hours	<ul style="list-style-type: none"> ▪ Conduct maintenance according to maintenance schedule (see chapter 11) ▪ Fault has to be receipted manually: Settings  → Code ▪ If code is already set → Settings 
039	SERVICE	This fault text occurs after 3000 operating hours	Carry out boiler system maintenance by authorised personnel
040	OVERHEAT ADD. BOILER	This fault text occurs if additional boiler temperature exceeds 92 °C	-
041	HEATING OFF	Boiler operation mode "HEATING OFF" is activated	-
042	BLOCKING PROTECTION	Blocking protection is active	-

No.	Fault report	Cause of fault	Fault correction
043	TIMEOUT ADD. BOILER	Additional boiler minimum flue gas temperature wasn't reached within 1 hour (operation mode: automatic/burner)	<ul style="list-style-type: none"> ▪ Check additional boiler
044	LEGIONELLA PROTECTION	Tank thermal disinfection active; Tank will be heated up to 70 °C	-
045	CHIMNEY SWEEP. MODE	Chimney sweep function active	(see chapter 9.4)
046	MOD.ERR EXT.	Communication error of CAN 2 to external module	<ul style="list-style-type: none"> ▪ Check module CAN connection ▪ Check module ▪ ☉ - contracting party
047	MOD.ERR INT.	Communication error of CAN 1 to external module	<ul style="list-style-type: none"> ▪ Check module CAN connection ▪ Check module ▪ ☉ - contracting party
048	MOD.ERR BOILER	Communication error to boiler module	<ul style="list-style-type: none"> ▪ Check module CAN connection ▪ Check module ▪ ☉ - contracting party
049	DATAERROR MEMORY EXTERNAL	Data adjustment error at external module	☉ - contracting party
050	DATAERROR MEMORY INTERNAL	Data adjustment error at internal module	☉ - contracting party
051	DATAERROR MEMORY BOILER	Data adjustment error at boiler module	☉ - contracting party
053	ADDITIONAL FLUE GAS SENSOR	Additional boiler flue gas temperature out of range	<ul style="list-style-type: none"> ▪ Check sensor, replace as necessary ▪ Check plug, replace as necessary ▪ Check wiring incl. connections, replace as necessary
054	EXTERNAL SET POINT	Ext. No Signal of external requirement or control (if line monitoring is active)	<ul style="list-style-type: none"> ▪ Check external (additional) control signal ▪ Check plug, replace as necessary ▪ Check cable incl. connection, replace as necessary
055	BACK FLOW SET	Back flow set temperature could not be reached during operation	<ul style="list-style-type: none"> ▪ Function check mixer with mixer motor ▪ Function check pump ▪ Check sensor position
056	SCREED BAKE OUT	Failure at screed bake out; Flow set temperature could not be reached	<ul style="list-style-type: none"> ▪ Function check mixer with mixer motor ▪ Function check pump ▪ Check sensor position ▪ Required heat output to high
057	CHECK DATA MODUL	Module parameter is not in the specified range	<ul style="list-style-type: none"> ▪ Restart T-Control ▪ Check boiler parameter
058	CHECK DATA BOILER	Boiler parameter is not in the specified range	<ul style="list-style-type: none"> ▪ Restart T-Control ▪ Check boiler parameter
059	CAN-ID	Set up module CAN-ID not useable	-

No.	Fault report	Cause of fault	Fault correction
060	INSERTION IN ACTION	Feeding screw temperature exceeded 70 °C during operation	<ul style="list-style-type: none"> ▪ Check fuel quality ▪ Check fuel storage room (fuel level) ▪ Clean intermediate hopper level sensor
061	INSERTION NOT IN ACTION	Feeding screw temperature exceeded 70 °C during non-operation	<ul style="list-style-type: none"> ▪ Chimney draught to high ▪ Feeding channel leakage ▪ Check fuel quality ▪ Shortening burn out time ▪ Underrun minimum running time
062	INSERTION BACKFIRE	Feeding screw temperature didn't fall below 70 °C after 30 minutes	<ul style="list-style-type: none"> ▪ Chimney draught to high ▪ Boiler system leakage ▪ Check fuel quality ▪ Shortening burn out time ▪ Underrun minimum running time ▪ ☎ - contracting party
063	OPEN BFP	Failure during burn back flap opening	<ul style="list-style-type: none"> ▪ Check BFP-motor ▪ Check fuel temperature ▪ Clean intermediate hopper level sensor ▪ Check drive arm ▪ ☎ - contracting party
064	CLOSE BFP	Failure during burn back flap closing	<ul style="list-style-type: none"> ▪ Check BFP-motor ▪ Check fuel temperature ▪ Clean intermediate hopper level sensor ▪ Check drive arm ▪ ☎ - contracting party
065	CONTACTS BFP	Failure at burn back flap end switch	<ul style="list-style-type: none"> ▪ ☎ - contracting party ▪ Carry out check BFP by specialist personnel
066	IGNITION	Heat supplier didn't ignite fuel within 15 minutes	<ul style="list-style-type: none"> ▪ Check fuel level ▪ Check burning parameters, adjust as necessary ▪ Check fuel level during firing
067	FIRE OUT	Flame monitoring device indicates no burning	<ul style="list-style-type: none"> ▪ Check fuel level ▪ Check burning parameters, adjust as necessary ▪ Clean intermediate hopper level sensor
068	TEMP. CONTROL	Fuel storage room temperature sensor has exceeded the maximum permissible temperature	<ul style="list-style-type: none"> ▪ Check fuel storage room ▪ Alarm fire brigade in case of fire
069	STL	Boiler temperature has exceeded the maximum permissible boiler temperature	<ul style="list-style-type: none"> ▪ Cool down boiler (< 75 °C) ▪ Quit STL
071	LAMBDA FUEL	Failure lambda probe	☎ - contracting party
072	CAN FAULT	Failure CAN bus	☎ - contracting party

No.	Fault report	Cause of fault	Fault correction
073	LAMBDA CALIBRATION	Failure during lambda probe calibration	☎ - contracting party
076	Fuel	Failure "FIRE OUT" (067) occurs for the second time within 2 hours.	<ul style="list-style-type: none"> ▪ Check fuel level ▪ Check burning parameters, adjust as necessary ▪ Clean intermediate hopper level sensor
077	Additional input	Additional input (e.g.: system pressure, CO-sensor) active	<ul style="list-style-type: none"> ▪ Check failure at additional input aggregate
078	NIVEAU LEVEL	Active intermediate hopper level sensor; low fuel level at intermediate hopper	<ul style="list-style-type: none"> ▪ Check fuel level ▪ Check discharge system (motor, screw, springs)
079	BARRIER LEVEL	Active feeding screw channel sensor; low fuel level in feeding system	<ul style="list-style-type: none"> ▪ Check fuel level ▪ Check discharge system (motor, screw, springs)
080	MP ROOM DISCHARGE	Active discharge screw motor protection	<ul style="list-style-type: none"> ▪ Check discharge system (motor, screw, springs) to debris
081	SPEED ID-FAN	Connection failure to ID fan	<ul style="list-style-type: none"> ▪ Check connection rotation speed sensor ▪ Check ID-fan ▪ ☎ ▪ ☎ - contracting party
082	GRATE CLEANING 1	Grate cleaning failure; motor damaged; grate linkage damaged or loosened; misaligned grate sensor	<ul style="list-style-type: none"> ▪ Check grate cleaning motor ▪ Check grate linkage ▪ Check grate cleaning end switch ▪ ☎ - contracting party
083	GRATE CLEANING 2	Failure grate cleaning; impossible to close grate; grate got stuck; grate linkage damaged or loosened	<ul style="list-style-type: none"> ▪ Remove debris ▪ Check grate cleaning motor ▪ Check grate linkage ▪ Check grate cleaning end switch ▪ ☎ - contracting party
084	GRATE CLEANING 3	Grate was opened during the combustion	<ul style="list-style-type: none"> ▪ Check grate cleaning motor ▪ Check grate linkage ▪ Check grate cleaning end switch
085	SUCTION MODE	Failure at pellet suction; fuel storage room empty; misaligned vacutrans flap; defect vacutrans flap sealing; hose leakage; suction hose leaks or is loose; suction turbine defect	<ul style="list-style-type: none"> ▪ Adjust suction cycles ▪ Check discharge system (motor, screw) ▪ Check fuel quality
086	SUCTION VALVE	Empty level container at compact container	<ul style="list-style-type: none"> ▪ Check vacutrans damper ▪ Check end switch vacutrans damper ▪ ☎ - contracting party
087	ASH CONTAINER	Ash container door is opened	<ul style="list-style-type: none"> ▪ Connect ash container ▪ Close ash container door
090	COMB. ROOM SENSOR	Burning chamber door end switch active; burning chamber door is open	<ul style="list-style-type: none"> ▪ Close burning chamber door

No.	Fault report	Cause of fault	Fault correction
093	ENDSW. ROOM DISCHARGE	Room discharge system end switch active	<ul style="list-style-type: none"> ▪ Blockage; remove trapped fuel ▪ Check fuel quality ▪ Clean intermediate hopper level sensor
095	CHECK ASH BOX	Set up ash container maintenance interval exceeded	<ul style="list-style-type: none"> ▪ Check ash container
096	BURNER STOP	Boiler operation mode „burner stop“ active	
180	KAS CHKDATA	Cascade parameter is not in the specified range	<ul style="list-style-type: none"> ▪ Restart T-Control ▪ Check cascade parameter
181	KAS CONNECTION	No connection to cascade	Check cascade connection
182	KAS OFFLINE	Boiler is not available to cascade	Establish data connection
189	KAS ALARM	Leading boiler couldn't be started or got stopped	<ul style="list-style-type: none"> ▪ Start leading boiler ▪ Ⓣ - contracting party

10.1 Not indicated faults

Fault	Cause of fault	Fault correction
Boiler output gradually decreases	Ash/slag on the grate; fly ash container is full; heat exchanger heavily clogged/sooted; inferior quality fuel	Reduce cleaning intervals or clean manually; empty the fly ash container; clean heat exchanger
Desired operating temperature is not reached	Inferior quality fuel; previous boiler output higher than current boiler output; fuel level too low	Replace fuel if necessary, install larger boiler; increase fuel level
Ash is emitted from the chimney	Fly ash container full; fuel contains of excessive finds or super fines; fan speed too high; chimney draught too high	Remove fly ash; replace fuel if necessary or retrofit flue gas deduster; reduce speeds; retrofit chimney draught regulator

11 MAINTENANCE SCHEDULE

(Some points have also been prescribed in accordance with TGPF H 118!)





For safety reasons, maintenance must only be carried out with the main switch turned off. However first of all, the system must be switched off by means of the On/Off button and you must wait for the burnout phase. If you have to climb into the storage tank or bunker, always make sure that there is a second person available to supervise you.
Potential carbon monoxide enrichment may put your life in danger.


11.1 Weekly Inspection

Item		Procedure
Total system		Check the whole boiler system (1) including the fuel storage room (2) visually for damages and wear. Repair discovered faults immediately.





11.2 Monthly inspection, at least every 1000 operating hours

Item		Procedure
Pivoting grate		Open burning chamber door (1)
Burning chamber		Check burning chamber stones and walls visually for damages and wear and conduct cleaning with scraper and broom (2), afterwards remove ash off burning chamber. Check and clean burning chamber vents (3).

Item		Procedure
<p>Pivoting grate Burning chamber</p>		<p>Check pivoting grate (4) visually for damages and wear</p> <p>Conduct function test of pivoting grate using the aggregate test</p>
<p>Ash container Fly ash container</p>		<p>Demount ash container cover and check ash level and empty ash container if necessary.</p>
<p>Control - functioning</p>		<p>Check display, operation and faults list (see chapter 9.9 and 10)</p> <p>Restart T-Control</p>

Item		Procedure
Control - faults		Open burning chamber door
		Check fault recognition and fault report Check if fault report e.g.: ASH CONTAINER FAULT is shown
Safety valve		Check safety valve tightness
System pressure		Check system pressure Minimum pressure: 1,5 bar (cold) Maximum pressure: see boiler plate
Fire extinguisher		Check fire extinguisher securing and seal as well as hose and nozzle (according to national standard)
Ash storage		Ash has to be stored in a non flammable, air tight container till disposal.
Boiler room		Remove flammable materials, except wood chips or pellets stored in a appropriate container, from the operating room
Fire protection		Check structural fire protection and fire doors (e.g.: self-locking fire door)




11.3 Biannual inspection

Item		Procedure
ID-fan		Function test of ID-fan using the aggregate test
		Check ID-Fan for abnormal or conspicuous running noises
Sensor barrier		Unscrew revision cover
		Clean sensors on the inside of the intermediate hopper with soft tissue on the left and right
Heat exchanger		Demount top boiler cover (1)
		Unscrew and remove heat exchanger insulation cover
		Remove deposit and check heat exchanger visually for damages and wear.
		Conduct function test of heat exchanger using the aggregate test

11.4 Annually inspection (service, notification)



Annual inspection, at least every 3000 operating hours

Item		Procedure
Maintenance		Conduct system maintenance by authorised personnel
Burn back protection device		Unscrew revision cover
		Check BFP flap visually for damages, wear and tightness
		Open BFP flap by using the aggregate test
		Position paper strip between hopper flange and BFP flap and close BFP flap afterwards. Try to pull out paper strip. If possible, adjust BFP flap. Conduct paper strip test at different positions
ID-fan		Unscrew 4x wing nut
		Remove and clean ID-fan with a brush

11.5 As needed

Item		Procedure
Chimney		Maintenance respectively Cleaning and inspection according to national standards
Fuel storage room		Fuel storage room emptying (at least after 3 fillings) and check visually for damages and wear (e.g.: stones, damaged walls,...)

12 EC DECLARATION OF CONFORMITY



Manufacturer address: **HERZ Energietechnik GmbH**
Herzstraße 1, 7423 Pinkafeld
Österreich/Austria

Declaration of machine: **HERZ pelletstar**

Type: **HERZ pelletstar 10**
HERZ pelletstar 20
HERZ pelletstar 30
HERZ pelletstar 45
HERZ pelletstar 60

Machine type: **Biomass furnace inclusive discharge system**

We declare herewith, that the above described machine / the above described product complies with the corresponding regulations of the following EC-Directives. The conformity is verified by the complete compliance with the following standards:

EU – directive	Standard
2006/95/EG Low tension units decree	EN 60335-1:2012 EN 60335-2-102:2007 EN 62233:2008
2004/108/EG Electromagnetic compatibility	EN 55014-1:2007 EN 61000-6-2:2006 EN 61000-3-2:2006 EN 61000-6-3:2007 EN 61000-3-3:2009
2006/42/EG Machine Guideline	ISO/TR 14121-2:2012 EN ISO 13849-1:2009
305/2011 Construction Products Guideline	EN 303-5:2012 TRVB H 118:2003
97/23/EG Pressure equipment	EN 287-1:2012

Person authorized to compile technical documentation:

HERZ ENERGIETECHNIK GMBH
A-7423 Pinkafeld, Herzstraße 1
Tel.: +43 (0)3357 142 84 0
Fax: +43 (0)3357 142 84 0-190

Pinkafeld, June 2015

DI Dr. Morteza Fesharaki - Managing director

13 INDEX DIRECTORY

A

Aggregate-Test	17
Ambient conditions	5

B

Boiler operation	11
------------------------	----

C

Chimney sweeping function	17
Commissioning	11

D

Declaration of conformity	73
---------------------------------	----

F

Fault reports and their corrections	57
---	----

I

Information overview	52
Introduction	2

M

Maintenance schedule

after 1000 operating hours	67
Annually inspection	71
as needed	72
Biannual inspection	70
Monthly inspection	67
Weekly Inspection	67

O

Operating condistions	12
-----------------------------	----

Operating conditions

Heating off	12
Lambda control	13

Operating temperatures	12
------------------------------	----

Operation and maintenance	5
---------------------------------	---

S

Safety devices

Safety temperature limiter	8
----------------------------------	---

Safety notes	4
---------------------------	----------

Basic safety information	5
Installation	5
Maintenance	6
Operation	5

Screed drying	38
----------------------------	-----------

T

Table of content	3
-------------------------------	----------

T-CONTROL	15
------------------------	-----------

Code – entry	18
Date and time	20
E-Mail status report	55
Fault messages and warnings	23
Modbus – settings	51
Network configuration	50
Screensaver	52
Sending E-mails	53
Server settings	56
Start screen	21
Symbols explanation	17

Temperaturmanager	14
--------------------------------	-----------

Terms and definitions

Additional boiler	48
Boiler	26
Buffer	30
External demand	46
Heating circuit	35
Hot water tank	32
Hydraulic compensator module	43
Net pump	44
Solar	41
Time mode	40
Zone valve	45


W

Warning notes	6
----------------------------	----------


14 ANNEX

14.1 Additional boiler module


Hydraulic recommendation 1



Hydraulic recommendation 2



Program 6



Österreich/Austria

Herz Energietechnik GmbH
Herzstraße 1
7423 Pinkafeld

☎ +43 (3357) / 42 84 0 – 0

☎ +43 (3357) / 42 84 0 – 190

✉ office-energie@herz.eu

Deutschland/Germany

Herz Armaturen GmbH
Fabrikstraße 76
D-71522 Backnang

☎ +49 (7191) 9021 – 0

☎ +49 (7191) 9021 – 79

✉ verkauf@herz-armaturen.de

